

Appendix

Apéndice

Anhang

Appendice

Appendix

Appendice

Bilaga

Apêndice

附錄

Приложение

	音色リスト	Tone List	Lista de tonos	Klangfarbenliste	Liste des sonorités	Toonlijst
①	グループ名	Group Name	Nombre del grupo	Gruppenname	Nom de groupe	Groepsnaam
②	番号	Number	Número	Nummer	Numéro	Nummer
③	音色名	Tone Name	Nombre del tono	Klangfarbename	Nom de sonorité	Toonnaam
④	プログラムチェンジ	Program Change	Cambio de programa	Programmwechsel	Changement de programme	Programmaverandering
⑤	バンクセレクトMSB	Bank Select MSB	MSB de selección de banco	Bankwahl MSB	MSB sélection de banque	Bankselectie MSB

	Lista dei timbri	Tonlista	Lista dos sons	音色表	Перечень тембров
①	Nome di gruppo	Gruppenamn	Nome do grupo	組名	Название группы
②	Numero	Nummer	Número	編號	Номер
③	Nome di timbro	Tonnamn	Nome do som	音色名	Название тембра
④	Cambio di programma	Programändring	Mudança de programa	程式變化	Смена программы
⑤	MSB di selezione banco	Bankval MSB	MSB de seleção de banco	庫選擇MSB	Выбор банка, старший байт

①	②	③	④	⑤	DSP	①	②	③	④	⑤	DSP
Piano	001	GRAND PIANO CONCERT	0	2	*	Elec.Piano	027	60'S ELEC.PIANO 2	4	19	*
Piano	002	GRAND PIANO BRIGHT	1	2		Elec.Piano	028	CHORUS E.PIANO 1	4	20	
Piano	003	GRAND PIANO STUDIO	0	3	*	Elec.Piano	029	CHORUS E.PIANO 2	4	21	
Piano	004	GRAND PIANO MODERN	0	4	*	Elec.Piano	030	PHASER E.PIANO 1	4	22	*
Piano	005	ROCK PIANO	1	3	*	Elec.Piano	031	PHASER E.PIANO 2	4	23	*
Piano	006	LA PIANO	1	4	*	Elec.Piano	032	AMP E.PIANO 1	4	24	*
Piano	007	DANCE PIANO 1	1	5		Elec.Piano	033	AMP E.PIANO 2	4	25	*
Piano	008	DANCE PIANO 2	1	6	*	Elec.Piano	034	CRUNCH E.PIANO	4	26	*
Piano	009	GRAND PIANO MELLOW	0	5	*	Elec.Piano	035	DIZZY E.PIANO	4	27	*
Piano	010	MONO PIANO 1	0	6		Elec.Piano	036	ANALOG E.PIANO 1	5	11	*
Piano	011	MONO PIANO 2	0	7	*	Elec.Piano	037	ANALOG E.PIANO 2	5	12	*
Piano	012	TACK PIANO	0	8	*	Elec.Piano	038	OFF VELO.CLAVI 1	7	2	
Piano	013	GRAND PIANO CLASSIC	0	9		Elec.Piano	039	OFF VELO.CLAVI 2	7	3	
Piano	014	GRAND PIANO DOLCE	0	10	*	Elec.Piano	040	CLAVI 1	7	4	
Piano	015	HONKY-TONK	3	2		Elec.Piano	041	CLAVI 2	7	5	
Piano	016	OCTAVE PIANO	3	3		Elec.Piano	042	CLAVI 3	7	6	
Piano	017	STRINGS PIANO	0	11	*	Elec.Piano	043	CLAVI 4	7	7	
Piano	018	SYNTH-STR.PIANO	0	12		Elec.Piano	044	WAH CLAVI 1	7	8	*
Piano	019	PIANO PAD	0	13		Elec.Piano	045	WAH CLAVI 2	7	9	*
Piano	020	CHOIR PIANO	0	14		Elec.Piano	046	CRUNCH CLAVI	7	10	*
Piano	021	PIANO CHIME	0	15		Elec.Piano	047	VIBRAPHONE 1	11	2	*
Piano	022	ELEC.GRAND PIANO	2	2		Elec.Piano	048	VIBRAPHONE 2	11	3	
Piano	023	MODERN E.G.PIANO	2	3		Elec.Piano	049	MARIMBA	12	2	
Piano	024	CHORUS E.G.PIANO	2	4	*	Elec.Piano	050	CELESTA	8	2	
Piano	025	OFF VELO.HARPSICHORD	6	2	*	Elec.Piano	051	BRIGHT CELESTA	8	3	*
Piano	026	HARPSICHORD	6	3		Elec.Piano	052	GLOCKENSPIEL	9	2	
Piano	027	COUPLED HARPSICHORD	6	4	*	Elec.Piano	053	MUSIC BOX 1	10	2	
Piano	028	HARPSICHORD & STRINGS	6	5		Elec.Piano	054	MUSIC BOX 2	10	3	*
Piano	029 - 058	USER TONES	0 - 29	64		Elec.Piano	055	XYLOPHONE	13	2	
Elec.Piano	001	AiR ELEC.PIANO 1	4	2		Elec.Piano	056	TUBULAR BELL	14	2	
Elec.Piano	002	AiR ELEC.PIANO 2	4	3		Elec.Piano	057	DULCIMER	15	2	
Elec.Piano	003	AiR ELEC.PIANO 3	4	4		Elec.Piano	058 - 097	USER TONES	0 - 39	65	
Elec.Piano	004	AiR ELEC.PIANO 4	4	5	*	Organ	001	DRAWBAR ORGAN 1	16	2	*
Elec.Piano	005	AiR ELEC.PIANO 5	4	6	*	Organ	002	DRAWBAR ORGAN 2	16	3	
Elec.Piano	006	AiR 60'S E.PIANO 1	4	7		Organ	003	DRAWBAR ORGAN 3	16	4	
Elec.Piano	007	AiR 60'S E.PIANO 2	4	8		Organ	004	DRAWBAR ORGAN 4	16	5	
Elec.Piano	008	AiR 60'S E.PIANO 3	4	9	*	Organ	005	JAZZ ORGAN 1	17	2	
Elec.Piano	009	AiR 60'S E.PIANO 4	4	10	*	Organ	006	JAZZ ORGAN 2	17	3	*
Elec.Piano	010	ELEC.PIANO 1	4	11		Organ	007	JAZZ ORGAN 3	17	4	
Elec.Piano	011	ELEC.PIANO 2	4	12		Organ	008	PERC.ORGAN 1	17	5	*
Elec.Piano	012	ELEC.PIANO 3	4	13		Organ	009	PERC.ORGAN 2	17	6	*
Elec.Piano	013	ELEC.PIANO 4	4	14		Organ	010	PERC.ORGAN 3	17	7	*
Elec.Piano	014	ELEC.PIANO 5	4	15		Organ	011	ROCK ORGAN 1	18	2	*
Elec.Piano	015	DIGITAL E.PIANO 1	5	2		Organ	012	ROCK ORGAN 2	18	3	
Elec.Piano	016	DIGITAL E.PIANO 2	5	3		Organ	013	ROCK ORGAN 3	18	4	
Elec.Piano	017	DIGITAL E.PIANO 3	5	4		Organ	014	ELEC.ORGAN 1	16	6	*
Elec.Piano	018	DIGITAL E.PIANO 4	5	5		Organ	015	ELEC.ORGAN 2	16	7	*
Elec.Piano	019	DIGITAL E.PIANO 5	5	6		Organ	016	ELEC.ORGAN 3	16	8	
Elec.Piano	020	DIGITAL E.PIANO 6	5	7		Organ	017	70'S ORGAN	17	8	*
Elec.Piano	021	DIGITAL E.PIANO 7	5	8		Organ	018	OVERDRIVE ORGAN 1	16	9	*
Elec.Piano	022	DIGITAL E.PIANO 8	5	9		Organ	019	OVERDRIVE ORGAN 2	16	10	*
Elec.Piano	023	DIGITAL E.PIANO 9	5	10		Organ	020	TREMOLO ORGAN	16	11	*
Elec.Piano	024	DYNO ELEC.PIANO 1	4	16		Organ	021	FULL DRAWBAR	16	12	
Elec.Piano	025	DYNO ELEC.PIANO 2	4	17	*	Organ	022	ROTARY ORGAN	17	9	
Elec.Piano	026	60'S ELEC.PIANO 1	4	18	*	Organ	023	CLICK ORGAN	17	10	*

①	②	③	④	⑤	DSP
Organ	024	SEQUENCE ORGAN	17	11	
Organ	025	GOSPEL ORGAN	17	12	*
Organ	026	PIPE ORGAN 1	19	2	
Organ	027	PIPE ORGAN 2	19	3	
Organ	028	CHAPEL ORGAN	19	4	
Organ	029	THEATER ORGAN	16	13	
Organ	030	REED ORGAN	20	2	
Organ	031	ACCORDION 1	21	2	
Organ	032	ACCORDION 2	21	3	
Organ	033	ACCORDION 3	21	4	
Organ	034	BANDONEON SOLO	23	4	
Organ	035	BANDONEON 1	23	2	
Organ	036	BANDONEON 2	23	3	
Organ	037	HARMONICA 1	22	2	
Organ	038	HARMONICA 2	22	3	
Organ	039 – 068	USER TONES	0 – 29	66	
Guitar	001	NYLON STR.GUITAR 1	24	2	
Guitar	002	NYLON STR.GUITAR 2	24	3	
Guitar	003	NYLON STR.GUITAR 3	24	4	*
Guitar	004	STEEL STR.GUITAR 1	25	2	
Guitar	005	STEEL STR.GUITAR 2	25	3	
Guitar	006	STEEL STR.GUITAR 3	25	4	
Guitar	007	12 STR.GUITAR	25	5	
Guitar	008	STEEL GT HARMONICS	31	2	
Guitar	009	JAZZ GUITAR	26	2	*
Guitar	010	OCT JAZZ GUITAR	26	3	
Guitar	011	CLEAN GUITAR 1	27	2	*
Guitar	012	CLEAN GUITAR 2	27	3	*
Guitar	013	CLEAN GUITAR 3	27	4	*
Guitar	014	CLEAN GUITAR 4	27	5	
Guitar	015	CHORUS CLEAN GUITAR 1	27	6	*
Guitar	016	CHORUS CLEAN GUITAR 2	27	7	*
Guitar	017	CRUNCH ELEC.GUITAR 1	27	8	*
Guitar	018	CRUNCH ELEC.GUITAR 2	27	9	*
Guitar	019	CRUNCH ELEC.GUITAR 3	27	10	*
Guitar	020	CHORUS CRUNCH GUITAR	27	11	*
Guitar	021	MUTE GUITAR 1	28	2	
Guitar	022	MUTE GUITAR 2	28	3	
Guitar	023	MUTE DIST.GUITAR	28	4	*
Guitar	024	OVERDRIVE GUITAR 1	29	2	*
Guitar	025	OVERDRIVE GUITAR 2	29	3	*
Guitar	026	DISTORTION GT 1	30	2	*
Guitar	027	DISTORTION GT 2	30	3	*
Guitar	028	DISTORTION GT 3	30	4	*
Guitar	029	DISTORTION GT 4	30	5	*
Guitar	030	STEEL GT + STRUM.NOISE M 1	25	32	
Guitar	031	STEEL GT + STRUM.NOISE M 2	25	33	
Guitar	032	STEEL GT + STRUM.NOISE M 3	25	34	
Guitar	033	CLEAN GUITAR M	27	32	
Guitar	034	CRUNCH E.GUITAR M 1	27	33	
Guitar	035	CRUNCH E.GUITAR M 2	27	34	
Guitar	036	DISTORTION GT M	30	32	
Guitar	037	OVERDRIVE GT M 1	29	32	
Guitar	038	OVERDRIVE GT M 2	29	33	
Guitar	039	MUTE OVERDRIVE GT M 1	28	32	
Guitar	040	MUTE OVERDRIVE GT M 2	28	33	
Guitar	041 – 060	USER TONES	0 – 19	67	
Bass	001	ACOUSTIC BASS 1	32	2	
Bass	002	ACOUSTIC BASS 2	32	3	*
Bass	003	RIDE BASS	32	4	
Bass	004	FINGERED BASS 1	33	2	
Bass	005	FINGERED BASS 2	33	3	*
Bass	006	FINGERED BASS 3	33	4	
Bass	007	FINGERED BASS 4	33	5	
Bass	008	PICKED BASS 1	34	2	
Bass	009	PICKED BASS 2	34	3	
Bass	010	SYNTH-BASS 1	38	2	
Bass	011	SYNTH-BASS 2	38	3	*
Bass	012	SYNTH-BASS 3	38	4	*
Bass	013	SYNTH-BASS 4	39	2	
Bass	014	SYNTH-BASS 5	39	3	*
Bass	015	SYNTH-BASS 6	39	4	*
Bass	016	TRANCE BASS	38	5	
Bass	017	ORGAN BASS	39	5	
Bass	018	FINGERED BASS M 1	33	32	

①	②	③	④	⑤	DSP
Bass	019	FINGERED BASS M 2	33	33	
Bass	020	SAW SYNTH-BASS M	39	32	
Bass	021	SYNTH-BASS M 1	38	32	
Bass	022	SYNTH-BASS M 2	38	33	
Bass	023 – 042	USER TONES	0 – 19	68	
Strings	001	STEREO STRINGS 1	49	2	
Strings	002	STEREO STRINGS 2	48	2	
Strings	003	STEREO STRINGS 3	48	3	
Strings	004	WIDE STRINGS	48	4	
Strings	005	STRINGS	48	5	
Strings	006	STRING ENSEMBLE 1	48	6	
Strings	007	STRING ENSEMBLE 2	48	7	
Strings	008	SLOW STRINGS	49	3	
Strings	009	BRIGHT STRINGS	48	8	*
Strings	010	WARM STRINGS	48	9	
Strings	011	PIZZICATO STRINGS	45	2	
Strings	012	CHAMBER	48	10	
Strings	013	OCTAVE STRINGS	48	11	
Strings	014	ORCHESTRA PAD	48	12	
Strings	015	SYNTH-STRINGS 1	50	2	*
Strings	016	SYNTH-STRINGS 2	50	3	
Strings	017	SYNTH-STRINGS 3	51	2	
Strings	018	70'S SYNTH-STR.	50	4	
Strings	019	80'S SYNTH-STR.	50	5	
Strings	020	FAST SYNTH-STRINGS	50	6	
Strings	021	SLOW SYNTH-STRINGS	50	7	
Strings	022	PHASER SYNTH-STRINGS	50	8	*
Strings	023	OCTAVE SYNTH-STRINGS	51	3	
Strings	024	VIOLIN	40	2	
Strings	025	SLOW VIOLIN	40	3	
Strings	026	VIOLA	41	2	
Strings	027	CELLO	42	2	
Strings	028	SLOW CELLO	42	3	
Strings	029	CONTRABASS	43	2	
Strings	030	HARP	46	2	
Strings	031	VIOLIN SECTION	48	13	
Strings	032	HARP & STRINGS	49	4	
Strings	033	CHOIR AAHS	52	2	
Strings	034	CHOIR STRINGS	52	3	
Strings	035	STRINGS VOICE	52	4	
Strings	036	SLOW CHOIR	52	5	
Strings	037	WAH CHOIR	52	6	*
Strings	038	VOICE DOO	53	2	
Strings	039	SYNTH-VOICE 1	54	2	
Strings	040	SYNTH-VOICE 2	54	3	
Strings	041	VOICE ENSEMBLE	54	4	
Strings	042	SYNTH-VOICE PAD	54	5	
Strings	043	CHORUS SYNTH-VOICE	54	6	*
Strings	044	ORCHESTRA HIT 1	55	2	
Strings	045	ORCHESTRA HIT 2	55	3	*
Strings	046 – 065	USER TONES	0 – 19	69	
Brass	001	STEREO BRASS	61	2	*
Brass	002	BRASS	61	3	
Brass	003	BRASS SECTION 1	61	4	
Brass	004	BRASS SECTION 2	61	5	
Brass	005	HARD BRASS	61	6	
Brass	006	BRASS SFZ	61	7	
Brass	007	BRASS & SAX	61	8	
Brass	008	SYNTH-BRASS 1	62	2	
Brass	009	SYNTH-BRASS 2	63	2	
Brass	010	SYNTH-BRASS 3	62	3	
Brass	011	WARM SYNTH-BRASS	62	4	
Brass	012	ANALOG SYNTH-BRASS	62	5	
Brass	013	80'S SYNTH-BRASS	62	6	
Brass	014	TRANCE BRASS	63	3	
Brass	015	CHORUS SYNTH-BRASS	62	7	*
Brass	016	SYNTH-BRASS PAD	63	4	
Brass	017	TRUMPET 1	56	2	*
Brass	018	TRUMPET 2	56	3	
Brass	019	MELLOW TRUMPET	56	4	
Brass	020	VELO.TRUMPET	56	5	
Brass	021	MUTE TRUMPET	59	2	
Brass	022	TROMBONE	57	2	
Brass	023	VELO.TROMBONE	57	3	
Brass	024	JAZZ TROMBONE	57	4	

①	②	③	④	⑤	DSP	①	②	③	④	⑤	DSP
Brass	025	FRENCH HORN	60	2		Synth	046	SYNTH-BASS+LEAD	87	3	
Brass	026	FRENCH HORN SECTION	60	3		Synth	047	REED LEAD	87	4	
Brass	027	TUBA	58	2		Synth	048	FANTASY 1	88	2	
Brass	028 – 047	USER TONES	0 – 19	70		Synth	049	FANTASY 2	88	3	*
Reed	001	ALTO SAX	65	2	*	Synth	050	NEW AGE	88	4	
Reed	002	BREATHY ALTO SAX	65	3	*	Synth	051	WARM VOX	89	2	
Reed	003	TENOR SAX	66	2	*	Synth	052	WARM PAD	89	3	
Reed	004	BREATHY TENOR SAX	66	3	*	Synth	053	HORN PAD	89	4	
Reed	005	SOPRANO SAX	64	2		Synth	054	POLYSYNTH	90	2	
Reed	006	BREATHY S.SAX	64	3		Synth	055	POLYSYNTH PAD	90	3	*
Reed	007	BARITONE SAX	67	2		Synth	056	SYNTH-PAD	90	4	
Reed	008	HARD A.SAX	65	4		Synth	057	VA SYNTH-PAD 1	90	6	*
Reed	009	SOFT T.SAX	66	4		Synth	058	VA SYNTH-PAD 2	90	7	*
Reed	010	T.SAXYS	66	5		Synth	059	VA SYNTH-PAD 3	90	8	*
Reed	011	CLARINET	71	2		Synth	060	POLY SAW	90	9	
Reed	012	VELO.CLARINET	71	3		Synth	061	BRIGHT SAW PAD 1	90	10	
Reed	013	OBOE	68	2		Synth	062	BRIGHT SAW PAD 2	90	11	
Reed	014	ENGLISH HORN	69	2		Synth	063	SPACE CHOIR	91	2	
Reed	015	BASSOON	70	2		Synth	064	STAR VOICE	91	3	*
Reed	016	FLUTE 1	73	2	*	Synth	065	GLASS PAD	92	2	
Reed	017	FLUTE 2	73	3		Synth	066	BOTTLE PAD	92	3	
Reed	018	JAZZ FLUTE	73	4		Synth	067	ETHNIC PAD	93	2	
Reed	019	PICCOLO	72	2		Synth	068	METAL PAD	93	3	
Reed	020	RECORDER	74	2		Synth	069	HALO PAD	94	2	
Reed	021	PAN FLUTE	75	2		Synth	070	SWEEP PAD	95	2	
Reed	022	BOTTLE BLOW	76	2		Synth	071	RAIN DROP	96	2	
Reed	023	WHISTLE	78	2		Synth	072	WOOD PAD	96	3	
Reed	024	OCARINA	79	2		Synth	073	SOUND TRACK	97	2	
Reed	025	SHAKUHACHI	77	2		Synth	074	CRYSTAL	98	2	
Reed	026 – 045	USER TONES	0 – 19	71		Synth	075	VIBRAPHONE BELL	98	3	
Synth	001	SAW LEAD 1	81	2		Synth	076	ATMOSPHERE	99	2	
Synth	002	SAW LEAD 2	81	3	*	Synth	077	ATMOSPHERE PAD	99	3	
Synth	003	SAW LEAD 3	81	4		Synth	078	STEEL PAD	99	4	
Synth	004	MELLOW SAW LEAD	81	5		Synth	079	BRIGHTNESS	100	2	
Synth	005	SLOW SAW LEAD	81	6		Synth	080	ECHO VOICE	102	2	
Synth	006	PULSE SAW LEAD	81	7		Synth	081	ECHO PAD	102	3	
Synth	007	TRANCE LEAD	81	8		Synth	082	POLY DROP	102	4	
Synth	008	SS LEAD	81	9		Synth	083	STAR THEME	103	2	
Synth	009	SQUARE LEAD 1	80	2		Synth	084	SPACE PAD	103	3	
Synth	010	SQUARE LEAD 2	80	3		Synth	085 – 134	USER TONES	0 – 49	72	
Synth	011	SQUARE LEAD 3	80	4	*	Ethnic	001	SITAR 1	104	2	
Synth	012	SLOW SQUARE LEAD	80	5		Ethnic	002	SITAR 2	104	3	
Synth	013	PHASER SQUARE LEAD	80	6	*	Ethnic	003	TANPURA 1	104	4	
Synth	014	PULSE LEAD 1	80	7		Ethnic	004	TANPURA 2	104	5	
Synth	015	PULSE LEAD 2	80	8		Ethnic	005	HARMONIUM 1	20	3	
Synth	016	SINE LEAD	80	9		Ethnic	006	HARMONIUM 2	20	4	
Synth	017	VELO.SINE LEAD	80	10		Ethnic	007	SAROD	105	4	
Synth	018	SQUARE PULSE LEAD	80	11		Ethnic	008	SHANAI	111	3	
Synth	019	VA SYNTH 1	80	12		Ethnic	009	TABLA	116	16	
Synth	020	VA SYNTH 2	80	13		Ethnic	010	ER HU 1	110	16	
Synth	021	VA SYNTH 3	80	14		Ethnic	011	ER HU 2	110	17	
Synth	022	VA SYNTH 4	80	15		Ethnic	012	ER HU 3	110	18	
Synth	023	VA SYNTH 5	80	16		Ethnic	013	YANG QIN 1	15	3	
Synth	024	VA SYNTH SEQ-BASS 1	81	10		Ethnic	014	YANG QIN 2	15	4	
Synth	025	VA SYNTH SEQ-BASS 2	81	11	*	Ethnic	015	PI PA 1	105	5	
Synth	026	SEQUENCE SAW	81	12		Ethnic	016	PI PA 2	105	6	
Synth	027	SAW ARPEGGIO	81	13		Ethnic	017	DI ZI 1	72	3	
Synth	028	CALLIOPE	82	2		Ethnic	018	DI ZI 2	72	4	
Synth	029	VENT LEAD	82	3		Ethnic	019	ZHENG 1	107	3	
Synth	030	PIPE LEAD	82	4		Ethnic	020	ZHENG 2	107	4	
Synth	031	CHIFF LEAD	83	2		Ethnic	021	XIAO	77	5	
Synth	032	VOICE LEAD	85	2		Ethnic	022	SHENG	109	3	
Synth	033	VOX LEAD	85	3		Ethnic	023	SUO NA	111	4	
Synth	034	CHARANG	84	2		Ethnic	024	CHINESE HARP	46	3	
Synth	035	PLUCK LEAD	84	3		Ethnic	025	ODU 1	105	7	
Synth	036	GT SYNTH-LEAD	84	4		Ethnic	026	ODU 2	105	8	
Synth	037	CHURCH LEAD	85	4		Ethnic	027	NEY	72	5	
Synth	038	DOUBLE VOICE LEAD	85	5		Ethnic	028	ARABIC ORGAN	16	14	
Synth	039	SYNTH-VOICE LEAD	85	6		Ethnic	029	ARABIC STRINGS	48	14	
Synth	040	FIFTH LEAD	86	2		Ethnic	030	SAZ	15	5	
Synth	041	FIFTH SAW LEAD	86	3		Ethnic	031	KANUN	15	6	
Synth	042	FIFTH SQUARE LEAD	86	4		Ethnic	032	BANJO	105	2	
Synth	043	FOURTH LEAD	86	5		Ethnic	033	MUTE BANJO	105	3	
Synth	044	SEVENTH SEQUENCE	86	6		Ethnic	034	THUMB PIANO	108	2	
Synth	045	BASS+LEAD	87	2		Ethnic	035	STEEL DRUMS	114	2	

①	②	③	④	⑤	DSP
Ethnic	036	RABAB	105	9	
Ethnic	037	SHAMISEN	106	2	
Ethnic	038	KOTO	107	2	
Ethnic	039 – 058	USER TONES	0 – 19	73	
GM	001	GM PIANO 1	0	0	
GM	002	GM PIANO 2	1	0	
GM	003	GM ELEC.GRAND PIANO	2	0	
GM	004	GM HONKY-TONK	3	0	
GM	005	GM E.PIANO 1	4	0	
GM	006	GM E.PIANO 2	5	0	
GM	007	GM HARPSICHORD	6	0	
GM	008	GM CLAVI	7	0	
GM	009	GM CELESTA	8	0	
GM	010	GM GLOCKENSPIEL	9	0	
GM	011	GM MUSIC BOX	10	0	
GM	012	GM VIBRAPHONE	11	0	
GM	013	GM MARIMBA	12	0	
GM	014	GM XYLOPHONE	13	0	
GM	015	GM TUBULAR BELL	14	0	
GM	016	GM DULCIMER	15	0	
GM	017	GM ORGAN 1	16	0	
GM	018	GM ORGAN 2	17	0	
GM	019	GM ORGAN 3	18	0	
GM	020	GM PIPE ORGAN	19	0	
GM	021	GM REED ORGAN	20	0	
GM	022	GM ACCORDION	21	0	
GM	023	GM HARMONICA	22	0	
GM	024	GM BANDONEON	23	0	
GM	025	GM NYLON STR.GUITAR	24	0	
GM	026	GM STEEL STR.GUITAR	25	0	
GM	027	GM JAZZ GUITAR	26	0	
GM	028	GM CLEAN GUITAR	27	0	
GM	029	GM MUTE GUITAR	28	0	
GM	030	GM OVERDRIVE GT	29	0	
GM	031	GM DISTORTION GT	30	0	
GM	032	GM GT HARMONICS	31	0	
GM	033	GM ACOUSTIC BASS	32	0	
GM	034	GM FINGERED BASS	33	0	
GM	035	GM PICKED BASS	34	0	
GM	036	GM FRETLESS BASS	35	0	
GM	037	GM SLAP BASS 1	36	0	
GM	038	GM SLAP BASS 2	37	0	
GM	039	GM SYNTH-BASS 1	38	0	
GM	040	GM SYNTH-BASS 2	39	0	
GM	041	GM VIOLIN	40	0	
GM	042	GM VIOLA	41	0	
GM	043	GM CELLO	42	0	
GM	044	GM CONTRABASS	43	0	
GM	045	GM TREMOLO STRINGS	44	0	
GM	046	GM PIZZICATO	45	0	
GM	047	GM HARP	46	0	
GM	048	GM TIMPANI	47	0	
GM	049	GM STRINGS 1	48	0	
GM	050	GM STRINGS 2	49	0	
GM	051	GM SYNTH-STRINGS 1	50	0	
GM	052	GM SYNTH-STRINGS 2	51	0	
GM	053	GM CHOIR AAHS	52	0	
GM	054	GM VOICE DOO	53	0	
GM	055	GM SYNTH-VOICE	54	0	
GM	056	GM ORCHESTRA HIT	55	0	
GM	057	GM TRUMPET	56	0	
GM	058	GM TROMBONE	57	0	
GM	059	GM TUBA	58	0	
GM	060	GM MUTE TRUMPET	59	0	
GM	061	GM FRENCH HORN	60	0	
GM	062	GM BRASS	61	0	
GM	063	GM SYNTH-BRASS 1	62	0	
GM	064	GM SYNTH-BRASS 2	63	0	
GM	065	GM SOPRANO SAX	64	0	
GM	066	GM ALTO SAX	65	0	
GM	067	GM TENOR SAX	66	0	
GM	068	GM BARITONE SAX	67	0	
GM	069	GM OBOE	68	0	
GM	070	GM ENGLISH HORN	69	0	
GM	071	GM BASSOON	70	0	

①	②	③	④	⑤	DSP
GM	072	GM CLARINET	71	0	
GM	073	GM PICCOLO	72	0	
GM	074	GM FLUTE	73	0	
GM	075	GM RECORDER	74	0	
GM	076	GM PAN FLUTE	75	0	
GM	077	GM BOTTLE BLOW	76	0	
GM	078	GM SHAKUHACHI	77	0	
GM	079	GM WHISTLE	78	0	
GM	080	GM OCARINA	79	0	
GM	081	GM SQUARE LEAD	80	0	
GM	082	GM SAW LEAD	81	0	
GM	083	GM CALLIOPE	82	0	
GM	084	GM CHIFF LEAD	83	0	
GM	085	GM CHARANG	84	0	
GM	086	GM VOICE LEAD	85	0	
GM	087	GM FIFTH LEAD	86	0	
GM	088	GM BASS+LEAD	87	0	
GM	089	GM FANTASY	88	0	
GM	090	GM WARM PAD	89	0	
GM	091	GM POLYSYNTH	90	0	
GM	092	GM SPACE CHOIR	91	0	
GM	093	GM BOWED GLASS	92	0	
GM	094	GM METAL PAD	93	0	
GM	095	GM HALO PAD	94	0	
GM	096	GM SWEEP PAD	95	0	
GM	097	GM RAIN DROP	96	0	
GM	098	GM SOUND TRACK	97	0	
GM	099	GM CRYSTAL	98	0	
GM	100	GM ATMOSPHERE	99	0	
GM	101	GM BRIGHTNESS	100	0	
GM	102	GM GOBLINS	101	0	
GM	103	GM ECHOES	102	0	
GM	104	GM SF	103	0	
GM	105	GM SITAR	104	0	
GM	106	GM BANJO	105	0	
GM	107	GM SHAMISEN	106	0	
GM	108	GM KOTO	107	0	
GM	109	GM THUMB PIANO	108	0	
GM	110	GM BAGPIPE	109	0	
GM	111	GM FIDDLE	110	0	
GM	112	GM SHANAI	111	0	
GM	113	GM TINKLE BELL	112	0	
GM	114	GM AGOGO	113	0	
GM	115	GM STEEL DRUMS	114	0	
GM	116	GM WOOD BLOCK	115	0	
GM	117	GM TAIKO	116	0	
GM	118	GM MELODIC TOM	117	0	
GM	119	GM SYNTH-DRUM	118	0	
GM	120	GM REVERSE CYMBAL	119	0	
GM	121	GM GT FRET NOISE	120	0	
GM	122	GM BREATH NOISE	121	0	
GM	123	GM SEASHORE	122	0	
GM	124	GM BIRD	123	0	
GM	125	GM TELEPHONE	124	0	
GM	126	GM HELICOPTER	125	0	
GM	127	GM APPLAUSE	126	0	
GM	128	GM GUNSHOT	127	0	
GM	129 – 138	USER TONES	0 – 9	74	
Drums	001	STANDARD SET 1	0	120	
Drums	002	STANDARD SET 2	1	120	
Drums	003	STANDARD SET 3	2	120	
Drums	004	STANDARD SET 4	3	120	
Drums	005	DANCE SET	29	120	
Drums	006	TRANCE SET	31	120	
Drums	007	HIP-HOP SET	9	120	
Drums	008	ROOM SET	8	120	
Drums	009	POWER SET	16	120	
Drums	010	ROCK SET	17	120	
Drums	011	ELECTRONIC SET	24	120	
Drums	012	SYNTH SET 1	25	120	
Drums	013	SYNTH SET 2	30	120	
Drums	014	JAZZ SET	32	120	
Drums	015	BRUSH SET	40	120	
Drums	016	ORCHESTRA SET	48	120	
Drums	017	ETHNIC SET 1	49	120	

①	②	③	④	⑤	DSP	①	②	③	④	⑤	DSP
Drums	018	ETHNIC SET 2	50	120		Hex Layer	051	STAIRWY RECORDER	50	97	*
Drums	019 – 038	USER TONES	0 – 19	125		Hex Layer	052	HEX SYNTH-LEAD 1	51	97	*
Hex Layer	001	PRIVIA SYNTH 1	0	97	*	Hex Layer	053	HEX SYNTH-LEAD 2	52	97	*
Hex Layer	002	PRIVIA SYNTH 2	1	97	*	Hex Layer	054	HEX SQR PULSE LEAD	53	97	*
Hex Layer	003	MANNHEIM KEYS	2	97		Hex Layer	055	CLASSIC SAW LEAD	54	97	
Hex Layer	004	ECHOES SYNTH	3	97	*	Hex Layer	056	SHORT SAWS	55	97	*
Hex Layer	005	TRANCE STAB	4	97	*	Hex Layer	057	SLOW SAW SWELL	56	97	*
Hex Layer	006	ICE CASTLE X5	5	97		Hex Layer	058	DECKARDS LEAD	57	97	*
Hex Layer	007	PRIVIA PAD	6	97	*	Hex Layer	059	DK LEAD	58	97	*
Hex Layer	008	MIDNIGHT SUN	7	97	*	Hex Layer	060	CZ FUNK LEAD	59	97	*
Hex Layer	009	HEX JUNGLE PF	8	97	*	Hex Layer	061	SYNTHFUL	60	97	*
Hex Layer	010	RAGTIMER	9	97	*	Hex Layer	062	FUSION LEAD	61	97	*
Hex Layer	011	LARRYS ROADZ	10	97	*	Hex Layer	063	HH LEAD	62	97	*
Hex Layer	012	SL MK1 TONE	11	97	*	Hex Layer	064	HEX SYNTH COMP	63	97	*
Hex Layer	013	5-VELO.WHIRLY	12	97	*	Hex Layer	065	JKS SWEET LEAD	64	97	*
Hex Layer	014	RAINDROP EP	13	97	*	Hex Layer	066	DANCE COMP	65	97	*
Hex Layer	015	SEEPY30 EP	14	97	*	Hex Layer	067	NU FUSION LEAD	66	97	*
Hex Layer	016	DEEP DYNO EP	15	97	*	Hex Layer	068	PWM SPLASH	67	97	*
Hex Layer	017	RMI EP	16	97	*	Hex Layer	069	PWM STACK	68	97	*
Hex Layer	018	HERBIES ROADZ	17	97	*	Hex Layer	070	PROG LEAD	69	97	*
Hex Layer	019	MODERN KEYS	18	97	*	Hex Layer	071	HEX SINE LEAD	70	97	*
Hex Layer	020	X-5	19	97	*	Hex Layer	072	HEX POLYSYNTH	71	97	*
Hex Layer	021	SWIRLING KEYS	20	97	*	Hex Layer	073	HEX 80'S SYNTH-STR.	72	97	
Hex Layer	022	HEX E.PIANO 1	21	97	*	Hex Layer	074	SAMPLE&HOLD	73	97	*
Hex Layer	023	HEX E.PIANO 2	22	97	*	Hex Layer	075	FANFARE HEX	74	97	*
Hex Layer	024	HEX E.PIANO 3	23	97	*	Hex Layer	076	ANGELS SING	75	97	*
Hex Layer	025	HEX E.PIANO 4	24	97	*	Hex Layer	077	SEPARATE	76	97	*
Hex Layer	026	HEX SPLIT EP	25	97	*	Hex Layer	078	STARTRAILS11	77	97	*
Hex Layer	027	HEX E.CLAVI 1	26	97	*	Hex Layer	079	TRANCE TONES	78	97	*
Hex Layer	028	HEX E.CLAVI 2	27	97	*	Hex Layer	080	GALAXY-5	79	97	*
Hex Layer	029	123467 BARS	28	97	*	Hex Layer	081	CZ PULSE PAD	80	97	*
Hex Layer	030	123469 BARS	29	97	*	Hex Layer	082	SLIP SLIDE PAD	81	97	*
Hex Layer	031	134578 BARS	30	97	*	Hex Layer	083	XTREEM PAD	82	97	*
Hex Layer	032	789 BARS	31	97	*	Hex Layer	084	PAD X560	83	97	
Hex Layer	033	VO ORGAN	32	97	*	Hex Layer	085	VOCAL PAD	84	97	*
Hex Layer	034	FF ORGAN	33	97		Hex Layer	086	CHORAL PAD	85	97	*
Hex Layer	035	FOOLED ORGAN	34	97	*	Hex Layer	087	RAINY DAY PAD	86	97	*
Hex Layer	036	WEDDING ORGAN	35	97	*	Hex Layer	088	SIMPLE PAD	87	97	
Hex Layer	037	HEX PIPE ORGAN	36	97	*	Hex Layer	089	PRIVIA VOYAGE	88	97	*
Hex Layer	038	LEAD GUITAR	37	97	*	Hex Layer	090	HOUSE TOP	89	97	*
Hex Layer	039	ROCK GTR BASS	38	97	*	Hex Layer	091	BELL RISER	90	97	*
Hex Layer	040	FAST OCT STRINGS	39	97		Hex Layer	092	HEAVEN SENT	91	97	*
Hex Layer	041	SYMPHONY ORCH.	40	97	*	Hex Layer	093	COSMO WAVES	92	97	*
Hex Layer	042	WOOD GLK TIMPANI	41	97	*	Hex Layer	094	ALLORING	93	97	*
Hex Layer	043	SILKY SMOOTH	42	97	*	Hex Layer	095	XMAS CHEER	94	97	*
Hex Layer	044	SYNTH SLIDE VELO.	43	97	*	Hex Layer	096	MAXIMUM	95	97	*
Hex Layer	045	PWM STRINGS	44	97	*	Hex Layer	097	PRIVIA HX	96	97	*
Hex Layer	046	NO NAME STREET	45	97	*	Hex Layer	098	OUT THERE	97	97	
Hex Layer	047	WATCHER STRINGS	46	97	*	Hex Layer	099	STRUCKK	98	97	*
Hex Layer	048	MIXED SAX BRASS	47	97	*	Hex Layer	100	AFRICA	99	97	
Hex Layer	049	SFZ HORNS	48	97	*	Hex Layer	101 – 200	USER TONES	0 – 99	98	
Hex Layer	050	EARTH BRASS	49	97							

①	②	③	④	⑤	DSP
ドラム音色リスト	Drum Assignment List	Lista de asignación de batería	Schlagzeug-Sound-Liste	Liste des sons de batterie	Drum toekenningslijst
音名	Key	Tecla	Tonhöhe	Tonalité	Klaviertoets
ノートナンバー	Note No.	Nº de nota	Noten-Nr.	No. de note	Noot Nr.
ドラムセット名	DRUMS SET NAME				
STANDARD SET 1 と同じ	indicates the same sound as STANDARD SET 1.	indica el mismo sonido que STANDARD SET 1.	Derselbe Sound wie bei STANDARD SET 1.	Indique le même son que STANDARD SET 1.	geeft hetzelfde geluid aan als STANDARD SET 1.
Lista di assegnazione batteria	Trumtilldelningslista	Lista das atribuições de bateria	鼓音分配表	Таблица присвоения клавишам звуков ударных	
Tasto	Tangent	Tecla	音調	Клавиша	
No. nota	Notnr.	Nº da nota	音符編號	Номер ноты	
indica lo stesso suono come STANDARD SET 1.	anger samma ljud som STANDARD SET 1.	indica o mesmo som que STANDARD SET 1.	表示聲音與 STANDARD SET 1 相同。	означает звук набора «STANDARD SET 1».	

1	2	3	4	5	6	7	
		STANDARD SET 1	STANDARD SET 2	STANDARD SET 3	STANDARD SET 4	DANCE SET	TRANCE SET
C-1	0	Tabla Ge	←	←	←	Dance Kick 1	←
	1	Tabla Ka	←	←	←	Dance Kick 2	←
D-1	2	Tabla Te	←	←	←	Dance Kick 3	←
	3	Tabla Na	←	←	←	Dance Kick 4	←
E-1	4	Tabla Tun	←	←	←	Dance Kick 5	←
F-1	5	Dholak Ge	←	←	←	Dance Snare 1	←
	6	Dholak Ke	←	←	←	Dance Snare 2	←
G-1	7	Dholak Ta 1	←	←	←	Dance Snare 3	←
	8	Dholak Ta 2	←	←	←	Dance Snare 4	←
A-1	9	Dholak Na	←	←	←	Dance Snare 5	←
	10	Dholak Ta 3	←	←	←	Dance Snare 6	←
B-1	11	Dholak Ring	←	←	←	Dance Snare 7	←
C0	12	Mridangam Tha	←	←	←	Dance Snare 8	←
	13	Mridangam Dhom	←	←	←	Dance Snare 9	←
D0	14	Mridangam Dni	←	←	←	Dance Tambourine	←
	15	Mridangam Dhin	←	←	←	Hip-Hop Snare 4	←
E0	16	Mridangam Num	←	←	←	Hip-Hop Snare 3	←
F0	17					Techno Snare	
	18					Hip-Hop Rim Shot	
G0	19					Hip-Hop Snare 3 Rev.	
	20					Synth2 Kick 1 Rev.	
A0	21					Reverse Cymbal Gate	
	22					Hip-Hop Snare 4 Gate	
B0	23		Standard2 Snare 1 mp			Hip-Hop Snare 3 Gate	
	24		Standard2 Snare 1 mf			Techno Snare Gate	
C1	25		Standard2 Snare 2 mp			Hip-Hop Side Stick Gate	
	26		Standard2 Snare 2 mf			Hand Clap 2 Gate	
D1	27	High Q	←	←	←		←
	28	Slap	←	←	←		←
F1	29	Scratch Push	←	←	←	Hip-Hop Scratch 1	←
	30	Scratch Pull	←	←	←	Hip-Hop Scratch 2	←
G1	31	Sticks	←	←	←		←
A1	32	Square Click	←	←	←		←
	33	Metronome Click	←	←	←		←
B1	34	Metronome Bell	←	←	←		←
	35	Standard1 Kick 2	Standard2 Kick 2	Standard3 Kick 2	Standard4 Kick 2	Synth2 Kick 2	Trance Kick 2
C2	36	Standard1 Kick 1	Standard2 Kick 1	Standard3 Kick 1	Standard4 Kick 1	Synth2 Kick 1	Trance Kick 1
	37	Side Stick	←	←	←	Synth2 Snare 1	Trance Side Stick
D2	38	Standard1 Snare 1	Standard2 Snare 1	Standard3 Snare 1	Standard4 Snare 1	Synth2 Snare 1	Trance Snare 1
	39	Hand Clap	←	←	←		Trance Hand Clap
E2	40	Standard1 Snare 2	Standard2 Snare 2	Standard3 Snare 2	Standard4 Snare 2	Synth2 Snare 2	Trance Snare 2
	41	Standard1 Low Tom 2	Standard2 Low Tom 2	Standard2 Low Tom 2	Standard2 Low Tom 2	Synth2 Low Tom 2	Standard2 Low Tom 2
F2	42	Standard1 Closed Hi-Hat	Standard2 Closed Hi-Hat	Standard3 Closed Hi-Hat	Standard4 Closed Hi-Hat	Synth2 Closed Hi-Hat 1	Trance Closed Hi-Hat 2
G2	43	Standard1 Low Tom 1	Standard2 Low Tom 1	Standard2 Low Tom 1	Standard2 Low Tom 1	Synth2 Low Tom 1	Standard2 Low Tom 1
	44	Standard1 Pedal Hi-Hat	Standard2 Pedal Hi-Hat	Standard3 Pedal Hi-Hat	Standard4 Pedal Hi-Hat	Synth2 Closed Hi-Hat 2	Trance Open Hi-Hat 1
A2	45	Standard1 Mid Tom 2	Standard2 Mid Tom 2	Standard2 Mid Tom 2	Standard2 Mid Tom 2	Synth2 Mid Tom 2	Standard2 Mid Tom 2
	46	Standard1 Open Hi-Hat	Standard2 Open Hi-Hat	Standard3 Open Hi-Hat	Standard4 Open Hi-Hat	Synth2 Open Hi-Hat	Trance Open Hi-Hat 2
B2	47	Standard1 Mid Tom 1	Standard2 Mid Tom 1	Standard2 Mid Tom 1	Standard2 Mid Tom 1	Synth2 Mid Tom 1	Standard2 Mid Tom 1
	48	Standard1 High Tom 2	Standard2 High Tom 2	Standard2 High Tom 2	Standard2 High Tom 2	Synth2 High Tom 2	Standard2 High Tom 2
C3	49	Standard1 Crash Cymbal 1	Standard2 Crash Cymbal 1	Standard2 Crash Cymbal 1	Standard2 Crash Cymbal 1	Standard2 Crash Cymbal 1	Standard2 Crash Cymbal 1
D3	50	Standard1 High Tom 1	Standard2 High Tom 1	Standard2 High Tom 1	Standard2 High Tom 1	Synth2 High Tom 1	Standard2 High Tom 1
	51	Standard1 Ride Cymbal 1	Standard2 Ride Cymbal 1	Standard2 Ride Cymbal 1	Standard2 Ride Cymbal 1	Standard2 Ride Cymbal 1	Standard2 Ride Cymbal 1
E3	52	Standard1 Chinese Cymbal	Standard2 Chinese Cymbal	Standard2 Chinese Cymbal	Standard2 Chinese Cymbal	Standard2 Chinese Cymbal	Standard2 Chinese Cymbal
	53	Standard1 Ride Bell	Standard2 Ride Bell	Standard2 Ride Bell	Standard2 Ride Bell	Standard2 Ride Bell	Standard2 Ride Bell
F3	54	Tambourine	←	←	←	←	Trance Tambourine
G3	55	Standard1 Splash Cymbal	Standard2 Splash Cymbal	Standard2 Splash Cymbal	Standard2 Splash Cymbal	Standard2 Splash Cymbal	Standard2 Splash Cymbal
	56	Cowbell	←	←	←	←	Standard2 Splash Cymbal
A3	57	Standard1 Crash Cymbal 2	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2
	58	Vibraslap	←	←	←	←	Standard2 Crash Cymbal 2
B3	59	Standard1 Ride Cymbal 2	Standard2 Ride Cymbal 2	Standard2 Ride Cymbal 2	Standard2 Ride Cymbal 2	Synth1 Kick 2	Standard2 Ride Cymbal 2
	60	High Bongo	←	←	←	Synth1 Kick 1	←
C4	61	Low Bongo	←	←	←	Synth1 Rim Shot	←
D4	62	Mute High Conga	←	←	←	Synth1 Snare 1	←
	63	Open High Conga	←	←	←	Synth1 Hand Clap	←
E4	64	Open Low Conga	←	←	←	Synth1 Snare 2	←
	65	High Timbale	←	←	←	Synth1 Low Tom 2	←
F4	66	Low Timbale	←	←	←	Synth1 Closed Hi-Hat 1	←
G4	67	High Agogo	←	←	←	Synth1 Low Tom 1	←
	68	Low Agogo	←	←	←	Synth1 Closed Hi-Hat 2	←
A4	69	Cabasa	←	←	←	Synth1 Mid Tom 2	←
	70	Maracas	←	←	←	Synth1 Open Hi-Hat	←
B4	71	Short High Whistle	←	←	←	Synth1 Mid Tom 1	←
	72	Long Low Whistle	←	←	←	Synth1 High Tom 2	←
C5	73	Short Guiro	←	←	←	Synth1 Crash Cymbal	←
	74	Long Guiro	←	←	←	Synth1 High Tom 1	←
D5	75	Claves	←	←	←	Synth1 Ride Cymbal	←
	76	High Wood Block	←	←	←	Standard2 Chinese Cymbal	←
E5	77	Low Wood Block	←	←	←	Standard2 Ride Bell	←
F5	78	Mute Cuica	←	←	←	Synth1 Tambourine	←
G5	79	Open Cuica	←	←	←	Standard2 Splash Cymbal	←
	80	Mute Triangle	←	←	←	Synth1 Cowbell	←
A5	81	Open Triangle	←	←	←	Standard2 Crash Cymbal 2	←
	82	Shaker	←	←	←	Vibraslap	←
B5	83	Jingle Ball	←	←	←	Synth1 Kick 3	←
	84	Bell Tree	←	←	←	Hip-Hop Kick 3	←
C6	85	Castanets	←	←	←	Standard3 Kick 1	←
	86	Mute Surdo	←	←	←	Standard3 Snare 1	←
D6	87	Open Surdo	←	←	←	Hand Clap 3	←
E6	88	Applause 1	←	←	←	Standard3 Snare 2	←
	89	Applause 2	←	←	←	Elec.Low Tom 2	←
F6	90					Hip-Hop Closed Hi-Hat	
G6	91					Elec.Low Tom 1	
	92					Hip-Hop Pedal Hi-Hat	
A6	93					Elec.Mid Tom 2	
	94					Hip-Hop Open Hi-Hat	
B6	95					Elec.Mid Tom 1	
	96					Elec.High Tom 2	
C7	97					Techno Cymbal	
	98					Elec.High Tom 1	
D7	99					Techno Ride	
E7	100						
	101						
F7	102					Standard2 Low Tom 2	
	103					Standard2 Closed Hi-Hat	
G7	104					Standard2 Low Tom 1	
	105					Standard2 Pedal Hi-Hat	
A7	106					Standard2 Mid Tom 2	
	107					Standard2 Open Hi-Hat	
B7	108					Standard2 Mid Tom 1	
	109	Tabla 1	←	←	←	Standard2 High Tom 2	
C8	110	Tabla 2	←	←	←	Standard2 Crash Cymbal 1	←
	111	Tabla 3	←	←	←	Standard2 High Tom 1	←
D8	112	Daf 1	←	←	←	Standard2 Ride Cymbal 1	←
	113	Daf 2	←	←	←		←
F8	114	Riq 1	←	←	←	Tambourine 3	←
	115	Riq 2	←	←	←	Tambourine 3	←
G8	116	Riq 3	←	←	←	Cabasa 2	←
	117	Davul 1	←	←	←	Maracas 2	←
A8	118	Davul 2	←	←	←	Claves 2	←
	119	Zill 1	←	←	←	Mute Triangle 2	←
B8	120	Zill 2	←	←	←	Open Triangle 2	←
	121	Ban Gu	←	←	←	Shaker 2	←
C9	122	Hu Yin Luo	←	←	←	Hand Clap	←
D9	123	Xiao Luo	←	←	←	Hand Clap 2	←
	124	Xiao Bo	←	←	←		←
F9	125	Low Tang Gu	←	←	←		←
	126	Mid Tang Gu	←	←	←		←
G9	127	High Tang Gu	←	←	←		←

1	2	3					
		HIP-HOP SET	ROOM SET	POWER SET	ROCK SET	ELECTRONIC SET	SYNTH SET 1
C-1	0	←	←	←	←	←	←
C-1	1	←	←	←	←	←	←
D-1	2	←	←	←	←	←	←
E-1	3	←	←	←	←	←	←
E-1	4	←	←	←	←	←	←
F-1	5	←	←	←	←	←	←
F-1	6	←	←	←	←	←	←
G-1	7	←	←	←	←	←	←
G-1	8	←	←	←	←	←	←
A-1	9	←	←	←	←	←	←
B-1	10	←	←	←	←	←	←
B-1	11	←	←	←	←	←	←
C0	12	←	←	←	←	←	←
C0	13	←	←	←	←	←	←
D0	14	←	←	←	←	←	←
E0	15	←	←	←	←	←	←
E0	16	←	←	←	←	←	←
F0	17	←	←	←	←	←	←
F0	18	←	←	←	←	←	←
G0	19	←	←	←	←	←	←
A0	20	←	←	←	←	←	←
A0	21	←	←	←	←	←	←
B0	22	←	←	←	←	←	←
B0	23	←	←	←	←	←	←
C1	24	←	←	←	←	←	←
C1	25	←	←	←	←	←	←
D1	26	←	←	←	←	←	←
E1	27	←	←	←	←	←	←
E1	28	←	←	←	←	←	←
F1	29	←	←	←	←	←	←
F1	30	←	←	←	←	←	←
G1	31	←	←	←	←	←	←
G1	32	←	←	←	←	←	←
A1	33	←	←	←	←	←	←
A1	34	←	←	←	←	←	←
B1	35	Hip-Hop Kick 2	Room Kick 2	Power Kick 2	Rock Kick 2	Elec.Kick 2	Synth1 Kick 2
C2	36	Hip-Hop Kick 1	Room Kick 1	Power Kick 1	Rock Kick 1	Elec.Kick 1	Synth1 Kick 1
C2	37	Hip-Hop Side Stick	←	←	Rock Side Stick	←	Synth1 Rim Shot
D2	38	Hip-Hop Snare 1	Room Snare 1	Power Snare 1	Rock Snare 1	Elec.Snare 1	Synth1 Snare 1
E2	39	Hip-Hop Hand Clap	←	←	←	←	Synth1 Hand Clap
E2	40	Hip-Hop Snare 2	Room Snare 2	Power Snare 2	Rock Snare 2	Elec.Snare 2	Synth1 Snare 2
F2	41	Standard2 Low Tom 2	Room Low Tom 2	Room Low Tom 2	Standard2 Low Tom 2	Elec.Low Tom 2	Synth1 Low Tom 2
F2	42	Hip-Hop Closed Hi-Hat	Standard2 Closed Hi-Hat	Standard2 Closed Hi-Hat	Rock Closed Hi-Hat	Standard2 Closed Hi-Hat	Synth1 Closed Hi-Hat 1
G2	43	Standard2 Low Tom 1	Room Low Tom 1	Room Low Tom 1	Standard2 Low Tom 1	Elec.Low Tom 1	Synth1 Low Tom 1
A2	44	Hip-Hop Pedal Hi-Hat	Standard2 Pedal Hi-Hat	Standard2 Pedal Hi-Hat	Rock Pedal Hi-Hat	Standard2 Pedal Hi-Hat	Synth1 Closed Hi-Hat 2
A2	45	Standard2 Mid Tom 2	Room Mid Tom 2	Room Mid Tom 2	Standard2 Mid Tom 2	Elec.Mid Tom 2	Synth1 Mid Tom 2
B2	46	Hip-Hop Open Hi-Hat	Standard2 Open Hi-Hat	Standard2 Open Hi-Hat	Rock Open Hi-Hat	Standard2 Open Hi-Hat	Synth1 Open Hi-Hat
B2	47	Standard2 Mid Tom 1	Room Mid Tom 1	Room Mid Tom 1	Standard2 Mid Tom 1	Elec.Mid Tom 1	Synth1 Mid Tom 1
C3	48	Standard2 High Tom 2	Room High Tom 2	Room High Tom 2	Standard2 High Tom 2	Elec.High Tom 2	Synth1 High Tom 2
C3	49	Standard2 Crash Cymbal 1	Standard2 Crash Cymbal 1	Standard2 Crash Cymbal 1	Rock Crash Cymbal	Standard2 Crash Cymbal 1	Synth1 Crash Cymbal
D3	50	Standard2 High Tom 1	Room High Tom 1	Room High Tom 1	Standard2 High Tom 1	Elec.High Tom 1	Synth1 High Tom 1
E3	51	Standard2 Ride Cymbal 1	Standard2 Ride Cymbal 1	Standard2 Ride Cymbal 1	Rock Ride Cymbal	Standard2 Ride Cymbal 1	Synth1 Ride Cymbal
E3	52	Standard2 Chinese Cymbal	Standard2 Chinese Cymbal	Standard2 Chinese Cymbal	Standard2 Chinese Cymbal	Reverse Cymbal	Standard2 Chinese Cymbal
F3	53	Standard2 Ride Bell	Standard2 Ride Bell	Standard2 Ride Bell	Standard2 Ride Bell	Standard2 Ride Bell	Standard2 Ride Bell
F3	54	←	←	←	←	←	Synth1 Tambourine
G3	55	Standard2 Splash Cymbal	Standard2 Splash Cymbal	Standard2 Splash Cymbal	Rock Splash Cymbal	Standard2 Splash Cymbal	Standard2 Splash Cymbal
A3	56	←	←	←	←	←	Synth1 Cowbell
A3	57	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2
B3	58	←	←	←	←	←	←
B3	59	Standard2 Ride Cymbal 2	Standard2 Ride Cymbal 2	Standard2 Ride Cymbal 2	Standard2 Ride Cymbal 2	Standard2 Ride Cymbal 2	Standard2 Ride Cymbal 2
C4	60	←	←	←	←	←	Standard2 Ride Cymbal 2
C4	61	←	←	←	←	←	Synth1 High Bongo
D4	62	←	←	←	←	←	Synth1 Low Bongo
E4	63	←	←	←	←	←	Synth1 Mute High Conga
E4	64	←	←	←	←	←	Synth1 Open High Conga
F4	65	←	←	←	←	←	Synth1 Open Low Conga
F4	66	←	←	←	←	←	←
G4	67	←	←	←	←	←	←
A4	68	←	←	←	←	←	←
A4	69	←	←	←	←	←	←
B4	70	←	←	←	←	←	←
B4	71	←	←	←	←	←	Synth1 Maracas
C5	72	←	←	←	←	←	←
C5	73	←	←	←	←	←	←
D5	74	←	←	←	←	←	←
E5	75	←	←	←	←	←	←
E5	76	←	←	←	←	←	Synth1 Claves
F5	77	←	←	←	←	←	←
F5	78	←	←	←	←	←	←
G5	79	←	←	←	←	←	←
A5	80	←	←	←	←	←	←
A5	81	←	←	←	←	←	←
B5	82	←	←	←	←	←	←
B5	83	←	←	←	←	←	←
C6	84	←	←	←	←	←	←
C6	85	←	←	←	←	←	←
D6	86	←	←	←	←	←	←
E6	87	←	←	←	←	←	←
E6	88	←	←	←	←	←	←
F6	89	←	←	←	←	←	←
F6	90	←	←	←	←	←	←
G6	91	←	←	←	←	←	←
G6	92	←	←	←	←	←	←
A6	93	←	←	←	←	←	←
A6	94	←	←	←	←	←	←
B6	95	←	←	←	←	←	←
C7	96	←	←	←	←	←	←
C7	97	←	←	←	←	←	←
D7	98	←	←	←	←	←	←
E7	99	←	←	←	←	←	←
E7	100	←	←	←	←	←	←
F7	101	←	←	←	←	←	←
F7	102	←	←	←	←	←	←
G7	103	←	←	←	←	←	←
G7	104	←	←	←	←	←	←
A7	105	←	←	←	←	←	←
A7	106	←	←	←	←	←	←
B7	107	←	←	←	←	←	←
B7	108	←	←	←	←	←	←
C8	109	←	←	←	←	←	←
C8	110	←	←	←	←	←	←
D8	111	←	←	←	←	←	←
E8	112	←	←	←	←	←	←
E8	113	←	←	←	←	←	←
F8	114	←	←	←	←	←	←
F8	115	←	←	←	←	←	←
G8	116	←	←	←	←	←	←
A8	117	←	←	←	←	←	←
A8	118	←	←	←	←	←	←
B8	119	←	←	←	←	←	←
B8	120	←	←	←	←	←	←
C9	121	←	←	←	←	←	←
C9	122	←	←	←	←	←	←
D9	123	←	←	←	←	←	←
E9	124	←	←	←	←	←	←
E9	125	←	←	←	←	←	←
F9	126	←	←	←	←	←	←
F9	127	←	←	←	←	←	←

1	2	3	SYNTH SET 2	JAZZ SET	BRUSH SET	ORCHESTRA SET	ETHNIC SET 1	ETHNIC SET 2
C-1	0	←						
C-1	1	←						
D-1	2	←						
E-1	3	←						
E-1	4	←						
F-1	5	←						
F-1	6	←						
G-1	7	←						
G-1	8	←						
A-1	9	←						
A-1	10	←						
B-1	11	←						
C0	12	←						
C0	13	←						
D0	14	←						
E0	15	←						
E0	16	←						
F0	17	←						
F0	18	←						
G0	19	←						
A0	20	←			Brush Slap 1 mp			
A0	21	←			Brush Slap 1 mf			
B0	22	←			Brush Slap 2			
B0	23	←		Jazz Snare 2 mp	Brush Swirl 2			
C1	24	←		Jazz Snare 1 mp	Brush Swirl 3			
C1	25	←		Jazz Snare 1 mf	Brush Swirl 4			
D1	26	←		Jazz Rim	Brush Swirl 5			
E1	27	←				Standard1 Closed Hi-Hat		
F1	28	←				Standard1 Pedal Hi-Hat		
F1	29	←				Standard1 Open Hi-Hat		
G1	30	←				Standard1 Ride Cymbal 1		
A1	31	←						
A1	32	←						
A1	33	←						
B1	34	←						
B1	35	←	Synth2 Kick 2	Jazz Kick 2	Jazz Kick 2	Jazz Kick 3	Standard2 Kick 2	Standard2 Kick 2
C2	36	←	Synth2 Kick 1	Jazz Kick 1	Brush Kick	Concert BD	Standard2 Kick 1	Standard2 Kick 1
C2	37	←	Synth1 Flim Shot	Jazz Side Stick	Brush Side Stick			
D2	38	←	Synth2 Snare 1	Jazz Snare 1	Brush Snare	Concert SD	Standard2 Snare 1	Standard2 Snare 1
E2	39	←			Brush Slap 1	Gastariets		
F2	40	←	Synth2 Snare 2	Jazz Snare 2	Brush Swirl 1	Concert SD	Standard2 Snare 2	Standard2 Snare 2
F2	41	←	Synth2 Low Tom 2	Jazz Low Tom 2	Brush Low Tom 2	Timpani F	Standard2 Low Tom 2	Standard2 Low Tom 2
F2	42	←	Synth2 Closed Hi-Hat 1	Standard2 Closed Hi-Hat	Standard2 Closed Hi-Hat	Timpani F#	Standard2 Closed Hi-Hat	Standard2 Closed Hi-Hat
G2	43	←	Synth2 Low Tom 1	Jazz Low Tom 1	Brush Low Tom 1	Timpani G	Standard2 Low Tom 1	Standard2 Low Tom 1
A2	44	←	Synth2 Closed Hi-Hat 2	Standard2 Closed Hi-Hat	Standard2 Closed Hi-Hat	Timpani G#	Standard2 Pedal Hi-Hat	Standard2 Pedal Hi-Hat
A2	45	←	Synth2 Mid Tom 2	Jazz Mid Tom 2	Brush Mid Tom 2	Timpani A	Standard2 Mid Tom 2	Standard2 Mid Tom 2
B2	46	←	Synth2 Open Hi-Hat	Standard2 Closed Hi-Hat	Standard2 Closed Hi-Hat	Timpani A#	Standard2 Open Hi-Hat	Standard2 Open Hi-Hat
B2	47	←	Synth2 Mid Tom 1	Jazz Mid Tom 1	Brush Mid Tom 1	Timpani B	Standard2 Mid Tom 1	Standard2 Mid Tom 1
C3	48	←	Synth2 High Tom 2	Jazz High Tom 2	Brush High Tom 2	Timpani c	Standard2 High Tom 2	Standard2 High Tom 2
C3	49	←	Standard2 Crash Cymbal 1	Standard2 Closed Hi-Hat	Brush Crash Cymbal 1	Timpani c#	Standard2 Crash Cymbal 1	Standard2 Crash Cymbal 1
D3	50	←	Synth2 High Tom 1	Jazz High Tom 1	Brush High Tom 1	Timpani d	Standard2 High Tom 1	Standard2 High Tom 1
E3	51	←	Standard2 Ride Cymbal 1	Standard2 Ride Cymbal 1	Brush Ride Cymbal 1	Timpani d#	Standard2 Ride Cymbal 1	Standard2 Ride Cymbal 1
E3	52	←	Standard2 Chinese Cymbal	Standard2 Chinese Cymbal	Standard2 Chinese Cymbal	Timpani e	Standard2 Chinese Cymbal	Standard2 Chinese Cymbal
F3	53	←	Standard2 Ride Bell	Standard2 Ride Bell	Brush Ride Bell	Timpani f	Standard2 Ride Bell	Standard2 Ride Bell
F3	54	←			Brush Tambourine			
G3	55	←	Standard2 Splash Cymbal	Standard2 Splash Cymbal	Brush Splash Cymbal	Standard2 Splash Cymbal	Standard2 Splash Cymbal	Standard2 Splash Cymbal
A3	56	←	Synth1 Cowbell					
A3	57	←	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2	Brush Crash Cymbal 2	Concert Cymbal 2	Standard2 Crash Cymbal 2	Standard2 Crash Cymbal 2
B3	58	←						
B3	59	←	Standard2 Ride Cymbal 2	Standard2 Ride Cymbal 2	Brush Ride Cymbal 2	Concert Cymbal 1	Standard2 Ride Cymbal 2	Standard2 Ride Cymbal 2
C4	60	←						
C4	61	←						
D4	62	←						
E4	63	←						
E4	64	←						
F4	65	←						
F4	66	←						
G4	67	←						
A4	68	←						
A4	69	←						
B4	70	←	Synth1 Maracas					Tablah 1
B4	71	←					Tabla Ge	Tablah 2
C5	72	←					Tabla Ka	Tablah 3
C5	73	←					Tabla Te	Daf 1
D5	74	←					Tabla Na	Daf 2
E5	75	←	Synth1 Claves				Tabla Na	Riq 1
E5	76	←					Tabla Tun	Riq 2
F5	77	←					Dholak Ge	Riq 3
F5	78	←					Dholak Ke	Davul 1
G5	79	←					Dholak Ta 1	Davul 2
A5	80	←					Dholak Ta 2	Zili 1
A5	81	←					Dholak Na	Zili 2
B5	82	←					Dholak Ta 3	Ban Gu
B5	83	←					Dholak Ring	Hu Yin Luo
C6	84	←					Mridangam Tha	Xiao Luo
C6	85	←					Mridangam Dhom	Xiao Bo
D6	86	←					Mridangam Dhi	Low Tang Gu
E6	87	←					Mridangam Dhin	Mid Tang Gu
E6	88	←					Mridangam Num	High Tang Gu
F6	89	←						
F6	90	←						
G6	91	←						
A6	92	←						
A6	93	←						
B6	94	←						
B6	95	←						
C7	96	←						
D7	97	←						
E7	98	←						
E7	99	←						
F7	100	←						
F7	101	←						
G7	102	←						
G7	103	←						
A7	104	←						
A7	105	←						
B7	106	←						
B7	107	←						
C8	108	←						
C8	109	←						
D8	110	←						
E8	111	←						
E8	112	←						
F8	113	←						
F8	114	←						
G8	115	←						
G8	116	←						
A8	117	←						
A8	118	←						
B8	119	←						
B8	120	←						
C9	121	←						
D9	122	←						
E9	123	←						
E9	124	←						
F9	125	←						
F9	126	←						
G9	127	←						

	リズムリスト	Rhythm List	Lista de ritmos	Rhythmenliste	Liste des rythmes	Ritmelijst
①	番号	Number	Número	Nummer	Numéro	Nummer
②	リズム名	Rhythm Name	Nombre del ritmo	Name des Rhythmus	Nom de rythme	Ritmennaam
	Lista dei ritmi	Rytmlista	Lista dos ritmos	節奏列表	Перечень стилей	
①	Numero	Nummer	Número	編號	Номер	
②	Nome di ritmo	Rytmmamn	Nome do ritmo	節奏名	Название стиля	

①	②	①	②	①	②
Pops		006	DISCO POP	World	
001	POP ROCK 1	007	TECHNO POP	American	
002	POP	008	TRANCE	001	DIXIE
003	ELECTROPOP	009	MODERN R&B	002	TEX-MEX
004	SYNTH POP 1	010	MODERN DANCE	003	FAST GOSPEL
005	SYNTH POP 2	011	DISCO SOUL	004	SLOW GOSPEL
006	FUNK 8 BEAT	012	TECHNO	005	HAWAIIAN
007	UK BEAT	013	HOUSE	Spanish/Eastern European	
008	6/8 POP	014	LATIN HOUSE	006	PASODOBLE
009	ACOUSTIC GUITAR POP	Jazz		007	CAUCASIAN
010	POP ROCK 2	001	SLOW BIG BAND	008	RUSSIAN CHANSON 1
011	SLOW SOUL	002	MIDDLE BIG BAND	009	RUSSIAN CHANSON 2
012	FAST SOUL	003	FAST BIG BAND	010	POLISH WALTZ
013	60's SOUL	004	ORCHESTRA SWING	Arabic/Oriental	
014	OLDIES SOUL	005	SWING	011	MALFOUF
015	60's POP	006	SLOW SWING	012	BALADI
016	60's SHUFFLE	007	JAZZ WALTZ	013	KHALJI
017	POP SHUFFLE	008	FOX TROT	014	ADANI
8 Beat		009	QUICKSTEP	015	MUS
001	STRAIGHT 8 BEAT	010	JAZZ COMBO 1	016	SIRTAKI
002	MELLOW 8 BEAT	European		Indian	
003	GUITAR 8 BEAT	001	SCHLAGER	017	BHANGRA
004	FAST 8 BEAT	002	POLKA	018	DADRA
005	8 BEAT	003	WALTZ 1	019	GARBA
006	OLDIES 8 BEAT	004	WALTZ 2	020	KEHARWA
007	60's 8 BEAT	005	SLOW WALTZ	021	DANDIYA
16 Beat		006	VIENNESE WALTZ	022	TEEN TAAL
001	16 BEAT	007	FRENCH WALTZ	023	BHAJAN
002	FUNK 16 BEAT	008	SERENADE	Chinese	
003	16 BEAT SHUFFLE	009	TANGO 1	024	GUANGDONG
004	FUNK SHUFFLE	010	MARCH 1	025	JIANGNAN
005	SLOW 16 BEAT	011	MARCH 2	026	BEIJING
006	16 BEAT POP	012	MARCH 3	027	DONGBEIYANGGE
007	LATIN FUSION	Latin		028	JINGJU
Rock		001	BOSSA NOVA	029	HUANGMEIXI
001	STRAIGHT ROCK	002	SLOW BOSSA NOVA	030	QINQIANG
002	SHUFFLE ROCK	003	BEGUINE	031	YUJU
003	6/8 ROCK	004	SAMBA 1	032	YAOZU
004	SHUFFLE BLUES	005	SAMBA 2	033	DAIZU
005	SLOW BLUES	006	MAMBO	034	MIAOZU
006	ROCK BLUES	007	RHUMBA	035	MENGGU
007	6/8 BLUES	008	CHA-CHA-CHA	036	XINJIANG
008	EP BLUES	009	MERENGUE	037	ZANGZU
009	R&B	010	BOLERO	038	CHINESE POP
010	SOFT ROCK	011	SALSA 1	Southeast Asian	
011	LATIN ROCK	012	SALSA 2	039	KRONCONG
012	ORGAN ROCK	013	REGGAE	040	DANGDUT
013	70's PIANO ROCK	014	POP REGGAE	Japanese	
014	ROCK	015	SKA	041	JAPANESE POP 1
015	60's ROCK 1	016	TANGO 2	042	JAPANESE POP 2
016	60's ROCK 2	017	LATIN DISCO	043	ENKA 1
017	OLDIES ROCK	018	FOLKLORE	044	ENKA 2
018	SLOW ROCK	019	REGGAETON 1	045	OKINAWA POP
019	ROCK & ROLL	020	REGGAETON 2	046	4/4 SHOUKA
020	50's PIANO ROCK	021	CUMBIA	047	3/4 SHOUKA
021	50's ROCK	022	CALYPSO	Country	
022	NEW ORLNS R&R	023	FORRO	001	COUNTRY POP
Dance		024	PAGODE	002	MODERN COUNTRY
001	PIANO HIP-HOP	025	BANDA	003	COUNTRY 8 BEAT
002	DANCE POP 1	026	PASILLO	004	COUNTRY 16 BEAT
003	ELECTRONIC HIP-HOP	027	ARGENTINE CUMBIA	005	COUNTRY BALLAD
004	HIP-HOP	028	PUNTA	006	COUNTRY SHUFFLE 1
005	DANCE POP 2	029	BACHATA	007	COUNTRY SHUFFLE 2

①	②
008	FINGER PICKING COUNTRY
009	COUNTRY WALTZ
010	BLUEGRASS
Various	
001	CHRISTMAS SONG
002	CHRISTMAS WALTZ
003	SCREEN SWING
004	SYMPHONY
005	STR QUARTET
Ballad	
001	PIANO ROCK BALLAD
002	90's BALLAD
003	MODERN BALLAD
004	ELECTRIC BALLAD
005	SLOW BALLAD 1
006	SLOW BALLAD 2
007	R&B BALLAD

①	②
008	16 BEAT BALLAD
009	BRUSH BALLAD
010	POP BALLAD
011	PIANO WALTZ BALLAD
012	90's 6/8 BALLAD
013	6/8 BALLAD 1
014	6/8 BALLAD 2
015	EASY LISTENING BALLAD
016	UNPLUGGED BALLAD
017	ROCK BALLAD 1
018	ROCK BALLAD 2
019	6/8 ROCK BALLAD
020	OLDIES BALLAD
Piano Rhythms	
001	PIANO 8 BEAT
002	PIANO BALLAD 1
003	PIANO BALLAD 2

①	②
004	EP BALLAD 1
005	EP BALLAD 2
006	BLUES BALLAD
007	JAZZ COMBO 2
008	JAZZ COMBO 3
009	RAGTIME
010	BOOGIE-WOOGIE
011	PIANO ROCK & ROLL
012	ARPEGGIO 1
013	ARPEGGIO 2
014	ARPEGGIO 3
015	PIANO MARCH 1
016	PIANO MARCH 2
017	STRIDE PIANO
018	WALTZ 3
019	WALTZ 4
020	WALTZ 5

- Piano Rhythmsの011～020番のリズムは、コードを入力しないと音が鳴りません。
- The rhythms of Piano Rhythms 011 to 020 do not sound unless a chord is being played.
- Los ritmos de Piano Rhythms 011 a 020 no suenan a menos que se toque un acorde.
- Die Rhythmen der Piano Rhythms 011 bis 020 ertönen nicht, wenn kein Akkord gespielt wird.
- Les rythmes de Piano Rhythms 011 à 020 ne résonnent pas si aucun accord n'est joué.
- De ritmes van Piano Rhythms 011 t/m 020 klinken niet tenzij een akkoord wordt gespeeld.
- I ritmi di Piano Rhythms da 011 a 020 non suonano se non viene eseguito un accordo.
- Rytmerna Piano Rhythms 011 till 020 ljuder inte såvida inte ett ackord spelas.
- Os ritmos de Piano Rhythms 011 a 020 não soam a menos que um acorde esteja sendo tocado.
- 除非彈奏和弦，否則Piano Rhythms 011 至020 的節奏不產生聲音。
- Стили «Piano Rhythms» 011—020 звучат только при взятии аккорда.

設定項目一覧

① 設定項目	
② ポートAのPart1からPart5に対する設定	
この設定項目を確認するには :	下表のこの列を見る :
本機の電源を切っても、常に保持される設定項目	Ⓐ
「Auto Resume」の設定が「On」の場合に、前回電源を切ったときの状態に復帰する設定項目	Ⓑ
レジストレーションに記憶される設定項目	Ⓒ
ワンタッチプリセットで変更される設定項目	Ⓓ
グランドピアノ音色選択時に変更される設定項目	Ⓔ
ミュージックプリセットで変更される設定項目	Ⓕ

Lista de parámetros

① Elemento de ajuste	
② Ajuste del Puerto A Parte 1 a Parte 5.	
Para comprobar este elemento de ajuste:	Vea esta columna de la siguiente tabla:
Elementos de ajuste que se almacenan siempre al cortar la alimentación	Ⓐ
Cuando se selecciona "On" para el ajuste "Auto Resume", los elementos de ajuste se restablecen a los que estaban en efecto la última vez que se cortó la alimentación	Ⓑ
Elementos de ajuste que se almacenan mediante Registro.	Ⓒ
Elementos de ajuste que se modifican mediante Preajuste de un toque.	Ⓓ
Elementos de ajuste que se modifican cuando se seleccionan tonos de piano de cola.	Ⓔ
Elementos de ajuste que se modifican mediante Preajuste musical.	Ⓕ

Liste des paramètres

① Paramètre	
② Réglage pour la partie 1 à la partie 5 du port A.	
Pour vérifier ces éléments :	Référez-vous à cette colonne du tableau suivant :
Les éléments toujours sauvegardés à la mise hors tension	Ⓐ
Les éléments qui reviennent aux réglages valides à la dernière mise hors tension lorsque « On » est sélectionné comme réglage pour « Auto Resume »	Ⓑ
Les éléments sauvegardés par consignment.	Ⓒ
Les paramètres changés par Préréglage monotouche.	Ⓓ
Les paramètres changés quand une sonorité de piano à queue est sélectionnée.	Ⓔ
Les paramètres changés par préréglage musical.	Ⓕ

Lista dei parametri

① Voce di impostazione	
② Impostazione per Porta A da Parte 1 a Parte 5.	
Per controllare questa voce di impostazione:	Fare riferimento a questa colonna nella tabella seguente:
Voci di impostazione che vengono sempre salvate quando si spegne l'alimentazione	Ⓐ
Quando è selezionato "On" per l'impostazione di "Auto Resume", le voci di impostazione che erano in vigore l'ultima volta che si è spenta l'alimentazione vengono ripristinate.	Ⓑ
Voci di impostazione salvate nella registrazione.	Ⓒ
Voci di impostazione cambiate dalla preselezione "One-Touch".	Ⓓ
Voci di impostazione cambiate quando viene selezionato un timbro di Grand Piano.	Ⓔ
Voci di impostazione cambiate dalla preregolazione musicale.	Ⓕ

Parameter List

① Setting Item	
② Setting for Port A Part 1 through Part 5.	
To check this setting item:	Refer to this column in the table below:
Setting items that are always saved when power is turned off	Ⓐ
When "On" is selected for the "Auto Resume" setting, setting items that are restored to those in effect the last time power was turned off	Ⓑ
Setting items stored by Registration.	Ⓒ
Setting items changed by One Touch Preset.	Ⓓ
Setting items changed when a Grand Piano tone is selected.	Ⓔ
Setting items changed by Music Preset.	Ⓕ

Parameterliste

① Einstellpunkt	
② Einstellung für Port A Part 1 bis Part 5.	
Zum Checken dieses Einstellpunkts:	Siehe Spalte in Tabelle unten:
Bei jedem Ausschalten gespeicherte Einstellpunkte	Ⓐ
Einstellpunkte, die beim Einschalten auf die beim letzten Ausschalten wirksamen Einstellungen gesetzt werden, wenn „On“ für „Auto Resume“ gewählt ist	Ⓑ
Durch Registrierung gespeicherte Einstellpunkte.	Ⓒ
Durch One-Touch-Preset geänderte Einstellpunkte.	Ⓓ
Durch Wahl einer Konzertflügel-Klangfarbe geänderte Einstellpunkte.	Ⓔ
Durch Musik-Preset geänderte Einstellpunkte.	Ⓕ

Parameterlijst

① Instelitem	
② Instelling voor Poort A deel 1 t/m deel 5.	
Controleren van dit instelitem:	Zie deze kolom in de onderstaande tabel:
Instelitem die altijd worden opgeslagen wanneer de stroom wordt uitgeschakeld	Ⓐ
Wanneer "On" wordt geselecteerd voor de "Auto Resume" instelling, instelitem die hersteld worden naar die van kracht waren de laatste maal dat de stroom werd uitgeschakeld	Ⓑ
Instelitem die opgeslagen worden d.m.v. registratie.	Ⓒ
Instelitem die veranderd worden door één-toets voorkeuze.	Ⓓ
Instelitem die veranderd worden wanneer een vleugeltoon wordt geselecteerd.	Ⓔ
Instelitem die veranderd worden door muziekvoorkeuze.	Ⓕ

Parameterlista

① Inställningspost	
② Inställning för Port A, del 1 till del 5.	
Att kontrollera denna inställningspost:	Se denna spalt i tabellen nedan:
Inställningsposter som alltid lagras när strömmen slås av	Ⓐ
Inställningsposter som återställs till de som gällde senaste gången strömmen slogs av när "On" är vald för inställningen "Auto Resume"	Ⓑ
Inställningsposter lagrade av register.	Ⓒ
Inställningsposter ändrade av direktförinställning.	Ⓓ
Inställningsposter ändrade vid val av en flygelton.	Ⓔ
Inställningsposter ändrade av musikförinställning.	Ⓕ

Lista dos parâmetros

❶	Item de definição	
❷	Definição da Parte 1 à Parte 5 da Porta A.	
	Para verificar este item de definição:	
	Consulte esta coluna na tabela abaixo:	
	Itens de definição que são armazenados toda vez que a alimentação é desligada	Ⓐ
	Quando "On" é selecionado para a definição "Auto Resume", os itens de definição que são restaurados aos itens em efeito na última vez que a alimentação foi desligada	Ⓑ
	Itens de definição armazenados por Registro	Ⓒ
	Itens de definição alterados pela Predefinição de um toque.	Ⓓ
	Itens de definição alterados quando um som de piano de cauda é selecionado.	Ⓔ
	Itens de definição alterados pela Predefinição de música.	Ⓕ

Перечень параметров

❶	Показатель настройки	
❷	Настройка для партий 1—5 порта A.	
	Для проверки показателя настройки следующей категории:	
	См. следующий столбец в нижеприведенной таблице:	
	Показатели настройки, которые всегда сохраняются при выключении инструмента	Ⓐ
	Показатели настройки, которые восстанавливаются с прошлого раза в том виде, в каком они были перед выключением инструмента (когда функция «Auto Resume» выставлена на «On»)	Ⓑ
	Показатели настройки, хранящиеся в регистрационной памяти	Ⓒ
	Показатели настройки, сменяющиеся при выборе установки мгновенного вызова	Ⓓ
	Показатели настройки, сменяющиеся при выборе рояльного тембра	Ⓔ
	Показатели настройки, сменяющиеся при выборе музыкальной предустановки	Ⓕ

❶	Ⓐ	Ⓑ	Ⓒ	Ⓓ	Ⓔ	Ⓕ
System Setting						
Speaker		○				
Touch Response		○	○			
Touch Off Velocity		○	○			
Metronome Count		○				
Tuning		○				
Temperament		○				
Temperament Base Note		○				
Accomp Temperament		○				
Stretch Tuning		○				
Brightness		○				
N.Gate Thresh	○					
Init By Wave		○				
Auto Resume	○					
Auto Power Off		○				
Duet						
On/Off		○	○	○	○	○*2
Octave		○	○			
Duet Pan		○	○			
Controller						
Knob1/ Knob2/ Knob3/ Modulation/ Pedal	Min Value		○	○		
	Max Value		○	○		
	Upper 1 Enable		○	○		
	Upper 2 Enable		○	○		
	Lower 1 Enable		○	○		
	Lower 2 Enable		○	○		
	Auto Resolution		○	○		
	RPN/NRPN MSB		○	○		
RPN/NRPN LSB		○	○			
Data Entry MSB/LSB		○	○			
Pedal Type		○	○			
Pedal Mode		○	○			
Upper 1 Pedal		○	○			
Upper 2 Pedal		○	○			
Lower 1 Pedal		○	○			
Lower 2 Pedal		○	○			
Bend Range		○	○			

參數表

❶	設定項	
❷	A埠1至5部分的設定。	
	要檢查此設定項：	
	參照下表中的欄目：	
	關機時總是保存設定項。	Ⓐ
	當 "Auto Resume" 設定被選擇為 "On" 時，復原上次關機時有效的設定項。	Ⓑ
	由登錄儲存的設定項。	Ⓒ
	由單鍵預設改變的設定項。	Ⓓ
	當三角鋼琴音色被選擇時改變的設定項。	Ⓔ
	由音樂預設改變的設定項。	Ⓕ

❶	Ⓐ	Ⓑ	Ⓒ	Ⓓ	Ⓔ	Ⓕ
Arpeggiator						
On/Off		○	○	○	○	○
Type		○	○	○	○	○
Hold		○	○	○	○	○
Part		○	○	○	○	○
Effect						
Reverb Parameter	Reverb Type		○	○	○	○
	Time		○	○	○	○
	Early Reflection		○	○	○	○
	High Damp		○	○	○	○
	Tone		○	○	○	○
	Return		○	○	○	○
	Chorus Type		○	○	○	○
	LFO Rate		○	○	○	○
Chorus Parameter	LFO Depth		○	○	○	○
	Feedback		○	○	○	○
	Tone		○	○	○	○
	Delay Time		○	○	○	○
	Delay Send		○	○	○	○
	Reverb Send		○	○	○	○
	Return		○	○	○	○
	Delay Type		○	○	○	○
Delay Parameter	Time		○	○	○	○
	Feedback		○	○	○	○
	High Damp		○	○	○	○
	Ratio L		○	○	○	○
	Ratio C		○	○	○	○
	Ratio R		○	○	○	○
	Level L		○	○	○	○
	Level C		○	○	○	○
	Level R		○	○	○	○
	Tempo Sync		○	○	○	○
Master EQ	Reverb Send		○	○	○	○
	Return		○	○	○	○
	Low Gain		○	○	○	○
	Low Frequency		○	○	○	○
	Mid1 Gain		○	○	○	○

①		(A)	(B)	(C)	(D)	(E)	(F)
Master EQ	Mid1 Frequency		○	○		○	
	Mid2 Gain		○	○		○	
	Mid2 Frequency		○	○		○	
	High Gain		○	○		○	
	High Frequency		○	○		○	
	Input Level		○	○		○	
	Output Level		○	○		○	
Master Comp	Threshold		○	○		○	
	Ratio		○	○		○	
	Level		○	○		○	
	Attack		○	○		○	
	Release		○	○		○	
Acoustic simulator	Position		○	○		○	
	Hammer Response		○				
	Damper Resonance		○				
	String Resonance		○				
	Damper Noise Level		○				
SysFx Bypass							
MasFx Bypass							
DSP Bypass							
MIDI							
Keyboard Channel			○				
Accomp Out			○				
Chord Judge			○				
Hi-Res Vel Out			○				
Local Control							
MIDI In Port			○				
MIDI Out/Thru			○				
Tone (②)							
Tone			○	○	○	○	○
Split Point			○	○*3			
Split On/Off			○	○	○	○	○
Transpose			○	○*3			
Part On/Off			○	○	○	○	○

①		(A)	(B)	(C)	(D)	(E)	(F)
Part Octave			○	○	○	○	○
Mixer (②)							
Volume			○	○	○	○	○
Pan			○	○	○	○	○
Coarse Tune			○	○	○	○	○
Fine Tune			○	○	○	○	○
Bend Range			○	○	○	○	○
Reverb Send			○	○	○	○	○
Chorus Send			○	○	○	○	○
Delay Send			○	○	○	○	○
Part On/Off							
Rhythm							
Rhythm No.			○	○		○	○
Accomp On/Off			○	○	○	○	
Chord Input Type			○	○		○	
Synchro state				○	○	○	○
Tempo			○	○	○	○	○
Accomp Part On/Off			○	○		○	○
Harmonize On/Off			○	○*4		○	○
Harmonize Type			○	○*4		○	○
Auto Chord			○	○	○	○	
Music Preset Key Shift			○	○			
Music Preset				○*1			○*1
Balance							
Accomp Volume			○	○			
MIDI Volume			○				
Keyboard Volume			○				
Audio Volume			○				
Line In Volume			○				
Metronome Volume			○				
Registration							
Bank			○				
Filter			○				

- *1 記憶した番号のコード進行を呼び出します。
 *2 ミュージックプリセットを選ぶと、デュエットはオフになります。
 *3 レジストレーションフィルターのToneをOnにしても変更されるパラメータです。
 *4 レジストレーションフィルターのRhythmをOnにしても変更されるパラメータです。
- *1 Recalls chord progression stored at memory number.
 *2 Selecting a Music Preset exits the Duet Mode.
 *3 These parameters are changed even when the registration filter Tone setting is On.
 *4 These parameters are changed even when the registration filter Rhythm setting is On.
- *1 Llama la progresión de acordes almacenada en el número de la memoria.
 *2 Si se selecciona un preajuste musical se sale del modo dúo.
 *3 Estos parámetros se cambian incluso cuando el ajuste de tono del filtro de registro está activado.
 *4 Estos parámetros se cambian incluso cuando el ajuste de ritmo del filtro de registro está activado.
- *1 Ruft die unter einer Speichernummer gespeicherte Akkordfolge auf.
 *2 Wählen eines Musik-Presets beendet den Duettmodus.
 *3 Diese Parameter werden geändert, auch wenn die Tone-Einstellung des Registrierungsfilters auf On gesetzt ist.
 *4 Diese Parameter werden geändert, auch wenn die Rhythm-Einstellung des Registrierungsfilters auf On gesetzt ist.
- *1 Rappelle la progression d'accords mémorisée sur un numéro de mémoire.
 *2 Sélectionner un pré réglage musical quitte le mode Duo.
 *3 Ces paramètres changent même quand le réglage de tonalité du filtre de consignation est activé.
 *4 Ces paramètres changent même quand le réglage de rythme du filtre de consignation est activé.
- *1 Roept akkoordprogressie opgeslagen onder geheugennummer op.
 *2 Door het selecteren van een muziekvoorkeuze wordt de duetmodus afgesloten.
 *3 Deze parameters worden gewijzigd ook wanneer de registratie filter toon instelling ingeschakeld is.
 *4 Deze parameters worden gewijzigd ook wanneer de registratie filter ritme instelling ingeschakeld is.

- *1 Richiama la progressione di accordi salvata al numero di memoria.
 *2 Selezionando una preregolazione musicale si esce dal modo di duetto.
 *3 Questi parametri vengono cambiati anche quando l'impostazione del filtro di registrazione Timbro è attivata.
 *4 Questi parametri vengono cambiati anche quando l'impostazione del filtro di registrazione Ritmo è attivata.
- *1 Återkallar akordföljd lagrad i minnesnummer.
 *2 Vid val av en musikförinställning lämnas duettläget.
 *3 Dessa parametrar ändras även när registerfiltrets toninställning är på.
 *4 Dessa parametrar ändras även när registerfiltrets rytminställning är på.
- *1 Chama a progressão de acordes armazenada no número da memória.
 *2 Selecionar uma Predefinição de música sai do modo de dueto.
 *3 Estes parâmetros são alterados mesmo que a definição do som do filtro de registro esteja ativada.
 *4 Estes parâmetros são alterados mesmo que a definição do ritmo do filtro de registro esteja ativada.
- *1 調用儲存記憶器編號下的和弦進程。
 *2 選擇音樂預設，退出二重奏模式。
 *3 即使當登錄過濾器的音色設定為開時，這些參數亦被改變。
 *4 即使當登錄過濾器的節奏設定為開時，這些參數亦被改變。
- *1. Вызывается аккордовая последовательность, хранящаяся в памяти под номером.
 *2. Выбор музыкальной предустановки приводит к выходу из режима «Дуэт».
 *3. Смена этих параметров происходит и в том случае, когда включен фильтр регистрационной памяти для параметра «Тембр».
 *4. Смена этих параметров происходит и в том случае, когда включен фильтр регистрационной памяти для параметра «Стиль».

	ミュージックプリセットリスト	Music Preset List	Lista de preajustes musicales	Musik-Preset-Liste	Liste des préréglages musicaux	Muziekvoorkeuzelijst
①	番号	Number	Número	Nummer	Numéro	Nummer
②	ミュージックプリセット名	Music Preset Name	Nombre del preajuste musical	Musik-Preset-Name	Nom de préréglage musical	Muziekvoorkeuzenaam
	Lista delle preregolazioni musicali	Musikförinställningslista	Lista das predefinições de música	音樂預設列表	Перечень музыкальных предустановок	
①	Numero	Nummer	Número	編號	Номер	
②	Nome della preregolazione musicale	Musikförinställningsnamn	Nome da predefinição de música	音樂預設名	Название музыкальной предустановки	

①	②	①	②	①	②
Pops		012	Lady Jam	024	Welcome Home
001	Soft Pop	013	Into Your H	025	Jazz Opera
002	Winter Pop	014	Euro Pop	026	NY City
003	Oldies Pop	015	Modern Dance	027	Soul & Jazz
004	Alpine Flora	016	Trance	028	Loneliness
005	Gypsy	017	ShuffleDance	029	Foggy
006	Rain Pop	Rock		030	Moon Swing
007	Movie Waltz	001	50's Rock 1	031	Jazz Ballad1
008	Funky Pop	002	50's Rock 2	032	Jazz Ballad2
009	Love Pop	003	Heartache	033	Jazz Ballad3
010	60's Pop	004	EP R&R	034	PatheticTrip
011	Rising Sun	005	Pop R&B	035	Night Sky
012	Pop Ska	006	60's Rock 1	036	Twilight
013	Weep Blues	007	60's Rock 2	037	Blues in F
014	Cartoon	008	60's Rock 3	038	Blues in Bb
015	Carol	009	60's Rock 4	039	Blues in C
016	My Life	010	60's Rock 5	040	II-V
017	Blue Love	011	Get Rock	041	II-V-I
018	Xmas Pop	012	Honky Rock	042	Minor Blues
019	Shuffle Pop1	013	Wild Rock	Classic	
020	Shuffle Pop2	014	Alligator	001	Canon
021	70's Soul	015	Movie Rock	002	Air G String
022	70's Pop	016	Pop Rock	003	Je Te Veux
023	West Coast	017	16Bt Shuffle	004	Adagio
024	Bossa Pop	018	Heat Up	005	Spring
025	Radio Pop	019	Hard Rock	006	Ave Maria
026	Crazy Roll	020	Grunge Rock	007	JesusBleibet
027	80's Pop 1	021	Modern Rock	008	Symphony 25
028	80's Pop 2	022	R&R	009	Symphony 40
029	UK Pop 1	023	Piano R&R	010	HungriaDance
030	UK Pop 2	024	Blues	011	Eine Kleine
031	A Feeling	025	8 Bars Blues	012	Pathetique
032	Calling	026	Riff Rock 1	013	Moonlight
033	80's EuroPop	027	Riff Rock 2	014	PstlSymphony
034	The World	028	Riff Rock 3	015	Ode To Joy
035	Mexican Pop	Jazz		016	Le Cygne
036	Guitar Pop	001	My Swing	017	Swan Lake
037	90's Pop	002	Your Things	018	Valse Fleurs
038	Wonder	003	Angel	019	Habanera
039	Modern Pop 1	004	Time Passes	020	Nocturne
040	Modern Pop 2	005	Piano Trio	021	Etude
041	MdmPopRock	006	Goodbye	022	FrenchCancan
042	Basic 1	007	Marine Dance	023	FantaisieImp
043	Basic 2	008	Vine Days	024	Humoresque
044	Basic 3	009	TraneChanges	025	Pavane
045	Basic 4	010	RhythmChange	026	Hope & Glory
046	Basic 5	011	Swing Mood	027	Moldau
Dance		012	The Big Mood	028	FromNewWorld
001	Funky Disco	013	Brown Jug	029	Reverie
002	Funky Clavi	014	Jazz Club	030	Nutcracker
003	Disco Soul	015	All Day Long	031	Liebestraume
004	70's Disco	016	Avenue	032	Gymnopedies
005	Disco Lady	017	Big Band 1	033	Jupiter
006	Staying	018	Big Band 2	034	Entertainer
007	Up&Down	019	Jazz Waltz 1	035	MapleLeafRag
008	80's Disco	020	Jazz Waltz 2	Trad	
009	80'sDancePop	021	Jazz Waltz 3	001	Michael Row
010	Bb Girl	022	Mode Jazz	002	GrndpasClock
011	Blv Disco	023	Tea Time	003	Troika

1	2
004	AuldLangSyne
005	Aloha Oe
006	O Sole Mio
007	Furusato
008	SzlaDziweczk
009	Battle Hymn
010	Condor
011	ScarboroFair
012	Danny Boy
013	Greensleeves
014	Annie Laurie
015	AmazingGrace
016	WeWishU Xmas
017	Silent Night
018	Joy To World
019	YankeeDoodle
020	Clarnt Polka
021	TaRaRaBoom
022	Double Eagle
023	Blauen Donau
024	Yellow Rose
025	BeautDreamer
Latin	
001	Satellite
002	Rio
003	Aqua
004	Single
005	Sea Shore
006	Poor Pitch
007	Mountain
008	Heartless
009	Carnival
010	Mythology
011	Tico-Tico
012	Beguine
013	Amapola
014	La Paloma
015	Banana Boat
016	Peanut
017	A Cup Of
018	Jamaica
019	60's Movie 1
020	60's Movie 2
021	The No.5
022	Everyday
023	Kiss Me

1	2
024	El Tango
025	El Choclo
026	Reggae 1
027	Reggae 2
028	Pop Reggae 1
029	Pop Reggae 2
030	Latin Rock 1
031	Latin Rock 2
032	Modern Latin
Country	
001	US Folk 1
002	US Folk 2
003	50's Country
004	70's Country
005	60's Folk
006	Tree
007	A Friend
008	Cowboy
009	Country Bld1
010	Country Bld2
011	Country Bld3
012	CountryWaltz
013	Mdrn Country
Ballad	
001	Love Ballad
002	R&B Ballad
003	Soul Ballad
004	Blues Ballad
005	MovieBallad1
006	MovieBallad2
007	MovieBallad3
008	Xmas Ballad
009	Love Me
010	Oldies Bld 1
011	Oldies Bld 2
012	Oldies Bld 3
013	Oldies Bld 4
014	E World
015	Guitar Bld 1
016	Guitar Bld 2
017	Moon Waltz
018	Theme
019	Paradise
020	60's Ballad1
021	60's Ballad2
022	Baroque Bld

1	2
023	FrenchBallad
024	Everywhere
025	Wonderful
026	70's Ballad1
027	70's Ballad2
028	70's Ballad3
029	My Song
030	Peace
031	Without
032	Soundtrack
033	Soft Ballad
034	Memories
035	Minor Ballad
036	Pop Ballad 1
037	Pop Ballad 2
038	PianoBallad1
039	PianoBallad2
040	Musical Bld
041	R Ballad
042	Love Song
043	80's Ballad1
044	80's Ballad2
045	80's Ballad3
046	80's Ballad4
047	Friends
048	Rock Ballad1
049	Rock Ballad2
050	Two Flames
051	90's Ballad1
052	90's Ballad2
053	90's Ballad3
054	90's SoulBld
055	I Always
056	6/8 Ballad
057	Wind Ballad
058	90's 6/8 Bld
059	My Ballad
060	MdrnSoulBld1
061	MdmSoulBld2
062	Mdm Pf Bld
063	Rap Ballad
064	Dance Ballad
065	MdmRock Bld
066	Slow Ballad
067	90's R&B Bld

アルペジオタイプ リスト		Arpeggio Type List	Lista de tipos de arpeggios	Arpeggiotyphen- Liste	Liste des types d'arpège	Arpeggio Type Lijst
①	バンク番号	Bank - Number	Banco - Número	Bank - Number	Banque - Numéro	Bank - Nummer
②	タイプ名	Type Name	Nombre del tipo	Typname	Nom de type	Typenaam
Lista dei tipi di arpeggio		Arpeggiotyplista	Lista dos tipos de arpejo	琶音種類表	Перечень типов арпеджио	
①	Banco - Numero	Bank - Nummer	Banco - Número	庫一編號	Банк - номер	
②	Nome di tipo	Typnamn	Nome do tipo	種類名	Название типа	

①	②	①	②	①	②	①	②
001	Screw Up	026	Soul Bass 1	051	Echo	076	UpDownB 4Oct
002	Screw Down	027	Soul Bass 2	052	Trill	077	Random
003	Panning Up	028	Shuffle Bass	053	Poly 1	078	Random 2Oct
004	Filtering	029	Funk Bass	054	Poly 2	079	Random 3Oct
005	Skip Up	030	Bossa Bass	055	Poly 3	080	Random 4Oct
006	Skip Down	031	8 Beat Bass	056	Poly 4	081	Repeat 1
007	Up Up Down	032	R&B Bass	057	Poly 5	082	Repeat 2
008	Down Down Up	033	Bass Line 1	058	Poly 6	083	Add 5th Up
009	Step Arp 1	034	Bass Line 2	059	Poly 7	084	Add 5th Down
010	Step Arp 2	035	Scale 1	060	Poly 8	085	Add 5th U/D
011	Seq Lines	036	Scale 2	061	Up	086	5th Up 1
012	Synth Seq 1	037	Scale 3	062	Up 2Oct	087	5th Up 2
013	Synth Seq 2	038	Scale 4	063	Up 3Oct	088	Octave Up 1
014	Seq Line 1	039	Blues Scale	064	Up 4Oct	089	Octave Up 2
015	Seq Line 2	040	Penta Scale	065	Down	090	Octave Down
016	Seq Line 3	041	Funky EP	066	Down 2Oct	091	Poly Up
017	Seq Line 4	042	Ragtime	067	Down 3Oct	092	Poly Down
018	Seq Line 5	043	Riff	068	Down 4Oct	093	Poly Line
019	Seq Line 6	044	Ska	069	Up Down A	094	4th Up
020	Seq Line 7	045	8 Beat	070	UpDownA 2Oct	095	4th Down
021	Prelude	046	12/8	071	UpDownA 3Oct	096	New Age
022	Arp 2 Oct	047	Shuffle	072	UpDownA 4Oct	097	Gtr Strk 1
023	9th Arp 1	048	Waltz	073	Up Down B	098	Gtr Strk 2
024	9th Arp 2	049	Shuffle Pop	074	UpDownB 2Oct	099	Latin Pf 1
025	9th Arp 3	050	Hard Rock	075	UpDownB 3Oct	100	Latin Pf 2

インストリスト		Instrument List	Lista de instrumentos	Instrumentenliste	Liste des instruments	Instrumentlijst
①	番号	Number	Número	Nummer	Numéro	Nummer
②	インスト名	Inst Name	Nombre del instrumento	Instr.-Name	Nom de l'instrument	Inst naam
Lista di strumenti		Instrumentlista	Lista de instrumentos	樂器列表	Список инструментов	
①	Numero	Nummer	Número	編號	Номер	
②	Nome di strumento	Instr.namn	Nome do instrumento	樂器名	Название инструмента	

①	②	①	②	①	②	①	②
001	Blank Inst	023	Syn1 Kick 3	045	Std2Snare2mp	067	Syn2 Snare 2
002	Std1 Kick 1	024	Syn2 Kick 1	046	Std2Snare2mf	068	TranceSnare1
003	Std1 Kick 2	025	Syn2 Kick 2	047	Std3 Snare 1	069	TranceSnare2
004	Std2 Kick 1	026	Syn2Kick1Rev	048	Std3 Snare 2	070	Dance Snare1
005	Std2 Kick 2	027	Trance Kick1	049	Std4 Snare 1	071	Dance Snare2
006	Std3 Kick 1	028	Trance Kick2	050	Std4 Snare 2	072	Dance Snare3
007	Std3 Kick 2	029	Dance Kick 1	051	HipHopSnare1	073	Dance Snare4
008	Std4 Kick 1	030	Dance Kick 2	052	HipHopSnare2	074	Dance Snare5
009	Std4 Kick 2	031	Dance Kick 3	053	HipHopSnare3	075	Dance Snare6
010	HipHop Kick1	032	Dance Kick 4	054	HpHpSnar3Rev	076	Dance Snare7
011	HipHop Kick2	033	Dance Kick 5	055	HipHopSnare4	077	Dance Snare8
012	HipHop Kick3	034	Jazz Kick 1	056	Room Snare 1	078	Dance Snare9
013	Room Kick 1	035	Jazz Kick 2	057	Room Snare 2	079	Techno Snare
014	Room Kick 2	036	Jazz Kick 3	058	Power Snare1	080	Jazz Snare 1
015	Power Kick 1	037	Brush Kick	059	Power Snare2	081	Jazz Snare 2
016	Power Kick 2	038	Concert BD	060	Rock Snare 1	082	JazzSnare1mp
017	Rock Kick 1	039	Std1 Snare 1	061	Rock Snare 2	083	JazzSnare1mf
018	Rock Kick 2	040	Std1 Snare 2	062	Elec.Snare 1	084	JazzSnare2mp
019	Elec.Kick 1	041	Std2 Snare 1	063	Elec.Snare 2	085	Brush Snare
020	Elec.Kick 2	042	Std2 Snare 2	064	Syn1 Snare 1	086	Brush Slap 1
021	Syn1 Kick 1	043	Std2Snare1mp	065	Syn1 Snare 2	087	Brush Swirl1
022	Syn1 Kick 2	044	Std2Snare1mf	066	Syn2 Snare 1	088	BrushSlap1mp

①	②	①	②	①	②	①	②
089	BrushSlap1mf	149	Jazz MidTom2	209	Techno Ride	269	Shaker
090	Brush Slap 2	150	Jazz LowTom1	210	BrshRideCym1	270	Shaker 2
091	Brush Swirl2	151	Jazz LowTom2	211	BrshRideCym2	271	Jingle Bell
092	Brush Swirl3	152	BrshHighTom1	212	BrshRideBell	272	Bell Tree
093	Brush Swirl4	153	BrshHighTom2	213	Concert Cym1	273	Castanets
094	Brush Swirl5	154	BrushMidTom1	214	Concert Cym2	274	Mute Surdo
095	Concert SD	155	BrushMidTom2	215	High Q	275	Open Surdo
096	Side Stick	156	BrushLowTom1	216	Slap	276	Applause 1
097	HpHpSidStick	157	Brsh LowTom2	217	Square Click	277	Applause 2
098	RockSidStick	158	Std1 ClHiHat	218	Sticks	278	Timpani F
099	Syn1 RimShot	159	Std1 PdHiHat	219	Metron.Click	279	Timpani F#
100	TrcSideStick	160	Std1 OpHiHat	220	Metron.Bell	280	Timpani G
101	HpHp RimShot	161	Std2 ClHiHat	221	Scratch Push	281	Timpani G#
102	Jz SideStick	162	Std2 PdHiHat	222	Scratch Pull	282	Timpani A
103	Jazz Rim	163	Std2 OpHiHat	223	HpHpScratch1	283	Timpani A#
104	Hand Clap	164	Std3 ClHiHat	224	HpHpScratch2	284	Timpani B
105	HipHpHndClap	165	Std3 PdHiHat	225	Tambourin1	285	Timpani c+
106	Syn1HandClap	166	Std3 OpHiHat	226	Tambourin2	286	Timpani c#+
107	Trc HandClap	167	Std4 ClHiHat	227	Tambourin3	287	Timpani d+
108	Hand Clap 2	168	Std4 PdHiHat	228	Syn1 Tambrin	288	Timpani d#+
109	Hand Clap 3	169	Std4 OpHiHat	229	TrcTambourin	289	Timpani e+
110	Std1HighTom1	170	HipHopClHiHat	230	DancTamborin	290	Timpani f+
111	Std1HighTom2	171	HipHopPdHHat	231	BrTambourn	291	Tabla Ge
112	Std1 MidTom1	172	HipHopOpHHat	232	Cowbell	292	Tabla Ka
113	Std1 MidTom2	173	RockClHiHat	233	Syn1 Cowbell	293	Tabla Te
114	Std1 LowTom1	174	RockPdHiHat	234	Vibraslap	294	Tabla Na
115	Std1 LowTom2	175	RockOpHiHat	235	High Bongo	295	Tabla Tun
116	Std2HighTom1	176	Syn1CHiHat1	236	Low Bongo	296	Dholak Ge
117	Std2HighTom2	177	Syn1CHiHat2	237	Syn1 HiBongo	297	Dholak Ke
118	Std2 MidTom1	178	Syn1 OpHiHat	238	Syn1LowBongo	298	Dholak Ta 1
119	Std2 MidTom2	179	Syn2CHiHat1	239	Mute HiConga	299	Dholak Ta 2
120	Std2 LowTom1	180	Syn2CHiHat2	240	Open HiConga	300	Dholak Na
121	Std2 LowTom2	181	Syn2 OpHiHat	241	OpenLowConga	301	Dholak Ta 3
122	RoomHighTom1	182	Trc ClsHiHat	242	Syn1MHiCong	302	Dholak Ring
123	RoomHighTom2	183	Trc OpHiHat1	243	Syn1OpHiCong	303	MridangamTha
124	RoomMidTom1	184	Trc OpHiHat2	244	Syn1OpLoCong	304	MridangmDhom
125	RoomMidTom2	185	Std1CrshCym1	245	High Timbale	305	MridangamDhi
126	RoomLowTom1	186	Std1CrshCym2	246	Low Timbale	306	MridangmDhin
127	RoomLowTom2	187	Std2CrshCym1	247	High Agogo	307	MridangamNum
128	ElecHighTom1	188	Std2CrshCym2	248	Low Agogo	308	Ban Gu
129	ElecHighTom2	189	RockCrashCym	249	Cabasa	309	Hu Yin Luo
130	Elec.MidTom1	190	Std1ChinsCym	250	Cabasa 2	310	Xiao Luo
131	Elec.MidTom2	191	Std2ChinsCym	251	Maracas	311	Xiao Bo
132	Elec.LowTom1	192	Std1SplshCym	252	Maracas 2	312	Low Tang Gu
133	Elec.LowTom2	193	Std2SplshCym	253	Syn1 Maracas	313	Mid Tang Gu
134	Syn1 HiTom1	194	RockSplshCym	254	ShrtHiWhistl	314	High Tang Gu
135	Syn1 HiTom2	195	ReverseCymb1	255	LongLoWhistl	315	Tablah 1
136	Syn1 MidTom1	196	Syn1CrashCym	256	Short Guiro	316	Tablah 2
137	Syn1 MidTom2	197	TechnoCymbal	257	Long Guiro	317	Tablah 3
138	Syn1 LowTom1	198	BrshCrshCym1	258	Claves	318	Daf 1
139	Syn1 LowTom2	199	BrshCrshCym2	259	Claves 2	319	Daf 2
140	Syn2 HiTom1	200	BrshSplshCym	260	Syn1 Claves	320	Riq 1
141	Syn2 HiTom2	201	Std1RideCym1	261	Hi WoodBlock	321	Riq 2
142	Syn2 MidTom1	202	Std1RideCym2	262	LowWoodBlock	322	Riq 3
143	Syn2 MidTom2	203	Std1RideBell	263	Mute Cuica	323	Davul 1
144	Syn2 LowTom1	204	Std2RideCym1	264	Open Cuica	324	Davul 2
145	Syn2 LowTom2	205	Std2RideCym2	265	MuteTriangle	325	Zill 1
146	JazzHighTom1	206	Std2RideBell	266	OpenTriangle	326	Zill 2
147	JazzHighTom2	207	RockRideCymb	267	MuteTriangl2		
148	Jazz MidTom1	208	Syn1 RideCym	268	OpenTriangl2		

波形式リスト		Wave List	Lista de ondas	Wellenformliste	Liste des ondes	Golflijst			
①	番号	Number	Número	Nummer	Numéro	Nummer			
②	波形式名	Wave Name	Nombre de la onda	Wellenformname	Nom de l'onde	Golfnaam			
Lista Wave		Våglista	Lista de ondas	音波列表	Перечень форм сигналов				
①	Numero	Nummer	Número	編號	Номер				
②	Nome Wave	Vågnamn	Nome da onda	音波名	Название формы сигнала				
001	GrPiano1-L	074	OffVelClav22	147	Nylon Gt 1 2	220	PickedBass 1	293	StringVoice1
002	GrPiano1-R	075	Clavi Off	148	NyIGt1 StNz1	221	PickedBass 2	294	StringVoice2
003	GrPiano2-L	076	ClaviAttack1	149	NyIGt1 StNz2	222	SynthBass1 1	295	Voice Doo
004	GrPiano2-R	077	ClaviAttack2	150	NyIGt1 Harmo	223	SynthBass1 2	296	Synth-Voice1
005	GrPiano3-L	078	Vibraphone 1	151	Nylon Gt 2 1	224	SynthBass1 3	297	Synth-Voice2
006	GrPiano3-R	079	Vibraphone 2	152	Nylon Gt 2 2	225	SynthBass1 4	298	SynVoice Pad
007	GrPiano4-L	080	Marimba	153	Steel Gt 1 1	226	SynthBass2 1	299	Cho.SynVoice
008	GrPiano4-R	081	Celesta	154	Steel Gt 1 2	227	SynthBass2 2	300	Orch.Hit 11
009	PianoAttack1	082	BriteCelesta	155	StIGt1 Harmo	228	SynthBass2 3	301	Orch.Hit 12
010	PianoAttack2	083	Glockenspiel	156	Steel Gt 2 1	229	SynthBass2 4	302	StereoBrass1
011	PianoAttack3	084	Music Box1 1	157	Steel Gt 2 2	230	SynthBass3 1	303	StereoBrass2
012	ElecG.Piano1	085	Music Box1 2	158	Steel Gt 2 3	231	SynthBass3 2	304	Brass1
013	ElecG.Piano2	086	Music Box2 1	159	Steel Gt 2 4	232	Synth-Bass 4	305	Brass2
014	MdnEG.Piano1	087	Music Box2 2	160	Steel Gt 3 1	233	Synth-Bass 5	306	BrassSect 11
015	MdnEG.Piano2	088	Xylophone	161	Steel Gt 3 2	234	Synth-Bass 6	307	BrassSect 12
016	Cho.EG.Piano	089	Tubular Bell	162	Steel Gt 3 3	235	Synth-Bass 7	308	BrassSect 21
017	OfVelHarpsi1	090	Dulcimer1	163	Steel Gt 3 4	236	Synth-Bass 8	309	BrassSect 22
018	OfVelHarpsi2	091	Dulcimer2	164	12StrGuitar1	237	Trance Bass	310	Hard Brass1
019	Harpsichord	092	DrawbarOrg 1	165	12StrGuitar2	238	Organ Bass	311	Hard Brass2
020	CouplHarpsi	093	DrawbarOrg 2	166	12StrGuitar3	239	Fing.Bass M1	312	Brass Sfx1
021	Harpsi & Str1	094	DrawbarOrg 3	167	12StrGuitar4	240	Fing.Bass M2	313	Brass Sfx2
022	Harpsi & Str2	095	DrawbarOrg 4	168	StIGtHarmo1	241	SawSynBassM1	314	Brass & Sax1
023	AiR EPiano11	096	JazzOrgan 1	169	StIGtHarmo2	242	SawSynBassM2	315	Brass & Sax2
024	AiR EPiano12	097	JazzOrgan 2	170	StIGtHarmo3	243	SawSynBassM3	316	Syn-Brass 11
025	AiR EPiano13	098	JazzOrgan 2 1	171	Jazz Guitar	244	SawSynBassM4	317	Syn-Brass 12
026	AiR EPiano14	099	JazzOrgan 2 2	172	OctJzGuitar1	245	SynthBassM11	318	Syn-Brass 21
027	AiR 60'sEP11	100	JazzOrgan 3 1	173	OctJzGuitar2	246	SynthBassM12	319	Syn-Brass 22
028	AiR 60'sEP12	101	JazzOrgan 3 2	174	CleanGt 1 1	247	SynthBassM21	320	Syn-Brass 31
029	AiR 60'sEP13	102	Perc.Organ 1	175	CleanGt 1 2	248	SynthBassM22	321	Syn-Brass 32
030	AiR 60'sEP14	103	PercOrgan 2 1	176	CleanGt 2 1	249	StreoStr 1 1	322	WarmSynBrs1
031	ElecPiano4 1	104	PercOrgan 2 2	177	CleanGt 2 2	250	StreoStr 1 2	323	WarmSynBrs2
032	ElecPiano4 2	105	PercOrgan 3 1	178	CleanGt 3 1	251	StreoStr 1 3	324	A.Syn-Brass
033	ElecPiano4 3	106	PercOrgan 3 2	179	CleanGt 3 2	252	StreoStr 1 4	325	80'sSynBrs1
034	ElecPiano5 1	107	Rock Organ 2	180	CleanGuitar 2	253	WideStrings1	326	80'sSynBrs2
035	ElecPiano5 2	108	RockOrgan3 1	181	ChoCleanGt11	254	WideStrings2	327	TranceBrass1
036	FM E.Piano	109	RockOrgan3 2	182	ChoCleanGt12	255	Strings	328	TranceBrass2
037	DynoEPiano21	110	Elec.Organ 1	183	Cho.CrunchGt	256	StrEnsemble1	329	ChoSynBrass1
038	DynoEPiano22	111	Elec.Organ 2	184	MuteGuitar11	257	StrEnsemble2	330	ChoSynBrass2
039	60'sEPiano21	112	Elec.Organ 3	185	MuteGuitar12	258	Slow Strings	331	SynBrassPad1
040	60'sEPiano22	113	70's Organ	186	Mute Guitar2	259	BriteString1	332	SynBrassPad2
041	Chorus EP 1 1	114	OverdrivOrg1	187	OverdrivGt11	260	BriteString2	333	Trumpet 11
042	Chorus EP 1 2	115	Tremolo Org	188	OverdrivGt12	261	Warm Strings	334	Trumpet 12
043	Chorus EP 2 1	116	Full Drawbar	189	Dist.Gt 4	262	PizzicatoStr	335	Trumpet 2
044	Chorus EP 2 2	117	Rotary Organ	190	StIGt+StNz11	263	Chamber1	336	Mellow Trp
045	DigitalEP1 1	118	Click Organ1	191	StIGt+StNz12	264	Chamber2	337	VeloTrumpet1
046	DigitalEP1 2	119	Click Organ2	192	StIGt+StNz21	265	Oct.Strings1	338	VeloTrumpet2
047	DigitalEP1 3	120	8'Organ1	193	StIGt+StNz22	266	Oct.Strings2	339	Mute Trumpet
048	DigitalEP2 1	121	8'Organ2	194	StIGt+StNz23	267	OrchestrPad1	340	Trombone
049	DigitalEP2 2	122	Seq.Organ1	195	StIGt+StNz31	268	OrchestrPad2	341	VelTrombone1
050	DigitalEP2 3	123	Seq.Organ2	196	StIGt+StNz32	269	SynStrings11	342	VelTrombone2
051	DigitalEP3 1	124	PipeOrgan 1 1	197	StIGt+StNz33	270	SynStrings12	343	JazzTrombone
052	DigitalEP3 2	125	PipeOrgan 1 2	198	StIGt+StNz34	271	Syn-Strings2	344	French Horn
053	DigitalEP3 3	126	PipeOrgan 2 1	199	StIGt+StNz35	272	Syn-Strings3	345	Fr.HornSect1
054	Digital EP4	127	PipeOrgan 2 2	200	Clean Gt M	273	70's Syn-Str	346	Fr.HornSect2
055	Analog EP1	128	ChapelOrgan 1	201	Crunch Gt M1	274	80's Syn-Str	347	Tuba
056	Analog EP2	129	ChapelOrgan2	202	Crunch GtM21	275	Fast Syn-Str	348	Alto Sax
057	EP Attack1	130	TheatrOrgan1	203	Crunch GtM22	276	Slow Syn-Str	349	BreathyASax1
058	EP Attack2	131	TheatrOrgan2	204	Dist.Gt M1	277	Phaz.Syn-Str	350	BreathyASax2
059	EP Attack3	132	Reed Organ	205	Dist.Gt M2	278	Oct.Syn-Str1	351	BreathyASax3
060	EP Attack4	133	Accordion 11	206	MuteOvdGt1	279	Oct.Syn-Str2	352	Tenor Sax
061	EP Attack5	134	Accordion 12	207	MuteOvdGtHm	280	Violin	353	BreathyTSax1
062	EP Attack6	135	Accordion 2	208	AcousBass1 1	281	Slow Violin	354	BreathyTSax2
063	EP Attack7	136	Accordion 31	209	AcousBass1 2	282	Viola	355	BreathyTSax3
064	EP Attack8	137	Accordion 32	210	AcousBass1 3	283	Cello	356	Soprano Sax
065	EP Attack9	138	BandneonSol1	211	AcousBass2 1	284	Slow Cello	357	BreathyTSax
066	EP Attack10	139	BandneonSol2	212	AcousBass2 2	285	Contrabass	358	Baritone Sax
067	EP Attack11	140	Bandoneon 11	213	AcousBass2 3	286	Harp	359	Hard A.Sax1
068	EP Attack12	141	Bandoneon 12	214	Ride Bass	287	ViolnSect.1	360	Hard A.Sax2
069	Analog EP 1	142	Bandoneon 2	215	FingerBass 1	288	ViolnSect.2	361	Soft T.Sax
070	Analog EP 2	143	Harmonica 1	216	FingerBass21	289	Harp&String1	362	T.Saxys1
071	OffVelClav11	144	Harmonica 21	217	FingerBass22	290	Harp&String2	363	T.Saxys2
072	OffVelClav12	145	Harmonica 22	218	FingerBass 3	291	Choir Aahs	364	Clarinet
073	OffVelClav21	146	Nylon Gt 1 1	219	FingerBass 4	292	ChoirString	365	VeloClarnet1

①	②	①	②	①	②	①	②	①	②
366	VeloClarnet2	451	Pluck Lead2	536	Brightness2	621	GM Organ 32	706	GM Bass+Lead1
367	Oboe	452	GI SynthLead1	537	Echo Voice1	622	GM PipeOrgan1	707	GM Bass+Lead2
368	English Horn	453	GI SynthLead2	538	Echo Voice2	623	GM PipeOrgan2	708	GM Bass+Lead3
369	Bassoon	454	Church Lead1	539	Echo Pad1	624	GM ReedOrgan	709	GM Bass+Lead4
370	Flute 1	455	Church Lead2	540	Echo Pad2	625	GM Accordion1	710	GM Fantasy1
371	Flute 21	456	Dbl VoiceLd1	541	Poly Drop1	626	GM Accordion2	711	GM Fantasy2
372	Flute 22	457	Dbl VoiceLd2	542	Poly Drop2	627	GM Harmonica	712	GM Warm Pad
373	Jazz Flute1	458	SynVoice Ld1	543	Star Theme1	628	GM Bandoneon1	713	GM SpaceCho1
374	Jazz Flute2	459	SynVoice Ld2	544	Star Theme2	629	GM Bandoneon2	714	GM SpaceCho2
375	Piccolo1	460	Fifth Lead1	545	Space Pad1	630	GM Nylon Gt1	715	GM BowGlass1
376	Piccolo2	461	Fifth Lead2	546	Space Pad2	631	GM Nylon Gt2	716	GM BowGlass2
377	Recorder	462	FifthSawLe1	547	Sitar 1	632	GM Steel Gt1	717	GM Halo Pad1
378	Pan Flute	463	FifthSawLe2	548	Sitar 21	633	GM Steel Gt2	718	GM Halo Pad2
379	Bottle Blow1	464	Fifth SqrLd1	549	Sitar 22	634	GM Mute Gt1	719	GM Sweep Pad
380	Bottle Blow2	465	Fifth SqrLd2	550	Tanpura 1	635	GM Mute Gt2	720	GM RainDrop1
381	Whistle	466	Fourth Lead1	551	Tanpura 21	636	GM Overdrive1	721	GM RainDrop2
382	Ocarina	467	Fourth Lead2	552	Tanpura 22	637	GM Overdrive2	722	GM SoundTrak1
383	Shakuhachi1	468	Seventh Seq1	553	Harmonium 1	638	GM Gt Harm.	723	GM SoundTrak2
384	Shakuhachi2	469	Seventh Seq2	554	Harmonium 21	639	GM AcousBass1	724	GM Crystal1
385	Saw Lead 11	470	Bass+Lead1	555	Harmonium 22	640	GM AcousBass2	725	GM Crystal2
386	Saw Lead 12	471	Bass+Lead2	556	Sarod	641	GM AcousBass3	726	GM Atmosphre1
387	Saw Lead 21	472	Syn-Bass+Ld1	557	Shanai	642	GM PickBass1	727	GM Atmosphre2
388	Saw Lead 22	473	Syn-Bass+Ld2	558	Tabla	643	GM PickBass2	728	GM Brightnes1
389	Saw Lead 3	474	Reed Lead1	559	Er Hu 11	644	GM FretlesBs1	729	GM Brightnes2
390	MlwSawLead1	475	Reed Lead2	560	Er Hu 12	645	GM FretlesBs2	730	GM Goblins1
391	MlwSawLead2	476	Fantasy 11	561	Er Hu 21	646	GM SlapBass1	731	GM Goblins2
392	SlowSawLead1	477	Fantasy 12	562	Er Hu 22	647	GM SlapBass21	732	GM Echoes
393	SlowSawLead2	478	Fantasy 21	563	Er Hu 31	648	GM SlapBass22	733	GM SF1
394	Pulse SawLd1	479	Fantasy 22	564	Er Hu 32	649	GM SynBass11	734	GM SF2
395	Pulse SawLd2	480	New Age1	565	Yang Qin 1	650	GM SynBass12	735	GM Sitar
396	Trance Lead1	481	New Age2	566	Yang Qin 21	651	GM Syn-Bass2	736	GM Banjo
397	Trance Lead2	482	Warm Vox1	567	Yang Qin 22	652	GM Violin	737	GM Shamisen
398	SS Lead1	483	Warm Vox2	568	Pi Pa 1	653	GM Viola	738	GM Koto
399	SS Lead2	484	Warm Pad	569	Pi Pa 21	654	GM Cello	739	GM Thumb Pno
400	SquarLead 11	485	Horn Pad1	570	Pi Pa 22	655	GM Contrabas	740	GM Bagpipe1
401	SquarLead 12	486	Horn Pad2	571	Di Zi 1	656	GM Trem.Str.	741	GM Bagpipe2
402	SquarLead 2	487	PolySynth1	572	Di Zi 21	657	GM Pizzicato	742	GM Fiddle
403	SquarLead 31	488	PolySynth2	573	Di Zi 22	658	GM Timpani	743	GM Shanai
404	SquarLead 32	489	PolysynthPd1	574	Zheng 11	659	GM Strings 1	744	GM TinkleBel
405	SlowSqrLead1	490	PolysynthPd2	575	Zheng 12	660	GM Syn-Str.1	745	GM Agogo
406	SlowSqrLead2	491	Syn-Pad1	576	Zheng 21	661	GM Syn-Str.2	746	GM SteelDrum1
407	Phaser SqrLd	492	Syn-Pad2	577	Zheng 22	662	GM ChoirAahs	747	GM SteelDrum2
408	Pulse Lead11	493	VA Syn-Pad 1	578	Xiao1	663	GM Voice Doo	748	GM WoodBlock
409	Pulse Lead12	494	VA Syn-Pad 2	579	Xiao2	664	GM Syn-Voice	749	GM Taiko
410	Pulse Lead21	495	VA Syn-Pad 3	580	Sheng	665	GM Orch.Hit1	750	GM Melo.Tom
411	Pulse Lead22	496	Poly Saw1	581	Suo Na	666	GM Orch.Hit2	751	GM Syn-Drum
412	Sine Lead	497	Poly Saw2	582	ChineseHarp1	667	GM Trombone	752	GM RevCymbal
413	Velo.SineLd1	498	BriteSawPd11	583	ChineseHarp2	668	GM Tuba	753	GM GtFrNoise
414	Velo.SineLd2	499	BriteSawPd12	584	Oud 1	669	GM MtTrumpet1	754	GM BrthNoise
415	Sqr PulseLd1	500	BriteSawPd21	585	Oud 2	670	GM MtTrumpet2	755	GM Seashore1
416	Sqr PulseLd2	501	BriteSawPd22	586	Ney	671	GM Fr.Horn1	756	GM Seashore2
417	VA Synth 1	502	Space Choir1	587	ArabicOrgan1	672	GM Fr.Horn2	757	GM Bird1
418	VA Synth 2	503	Space Choir2	588	ArabicOrgan2	673	GM GSynBrass11	758	GM Bird2
419	VA Synth 3	504	Star Voice1	589	Arabic Str.1	674	GM GSynBrass12	759	GM Telephone
420	VA Synth 4	505	Star Voice2	590	Arabic Str.2	675	GM GSynBrass21	760	GM Helicopt
421	VA Synth 5	506	Glass Pad1	591	Saz	676	GM GSynBrass22	761	GM Applause1
422	VA Synth 6	507	Glass Pad2	592	Kanun	677	GM Sop.Sax	762	GM Applause2
423	VA Synth 7	508	Bottle Pad1	593	Banjo	678	GM Bar.Sax	763	GM Gunshot
424	VA Synth 8	509	Bottle Pad2	594	Mute Banjo	679	GM Oboe	764	Sin Wave
425	VA Synth 9	510	Ethnic Pad1	595	Thumb Piano	680	GM Eng.Horn	765	TrianglWave1
426	VA Synth 10	511	Ethnic Pad2	596	Steel Drums1	681	GM Bassoon	766	TrianglWave2
427	VA Synth 11	512	Metal Pad1	597	Steel Drums2	682	GM Clarinet	767	TrianglWave3
428	VA Synth 12	513	Metal Pad2	598	Rabab1	683	GM Piccolo	768	SawtothWave1
429	VA Synth 13	514	Halo Pad1	599	Rabab2	684	GM Recorder	769	SawtothWave2
430	VA SynSeqBs1	515	Halo Pad2	600	Shamisen	685	GM Pan Flute	770	SawtothWave3
431	VA SynSeqBs2	516	Sweep Pad1	601	Koto	686	GM BotleBlow	771	SawtothWave4
432	VA SynSeqBs3	517	Sweep Pad2	602	GM E.G.Piano	687	GM Shakuhach1	772	SawtothWave5
433	SequenceSaw1	518	Rain Drop1	603	GM E.Piano11	688	GM Shakuhach2	773	SawtothWave6
434	SequenceSaw2	519	Rain Drop2	604	GM E.Piano12	689	GM Ocarina	774	Square Wave1
435	SawArpeggio1	520	Wood Pad1	605	GM E.Piano 2	690	GM Sqr.Lead1	775	Square Wave2
436	SawArpeggio2	521	Wood Pad2	606	GM Harpsi.1	691	GM Sqr.Lead2	776	Square Wave3
437	Calliope1	522	Sound Track1	607	GM Harpsi.2	692	GM Saw Lead1	777	Square Wave4
438	Calliope2	523	Sound Track2	608	GM Clavi	693	GM Saw Lead2	778	Square Wave5
439	Vent Lead	524	Crystal1	609	GM Celesta	694	GM Calliope1	779	Pulse Wave1
440	Pipe Lead1	525	Crystal2	610	GM Glocken.	695	GM Calliope2	780	Pulse Wave2
441	Pipe Lead2	526	Vib Bell1	611	GM MusicBox1	696	GM ChiffLead1	781	Pulse Wave3
442	Chiff Lead1	527	Vib Bell2	612	GM MusicBox2	697	GM ChiffLead2	782	Pulse Wave4
443	Chiff Lead2	528	Atmosphere1	613	GM Vibraphon	698	GM Charang1	783	Pulse Wave5
444	Voice Lead1	529	Atmosphere2	614	GM Marimba	699	GM Charang2	784	Pulse Wave6
445	Voice Lead2	530	AtmspherePd1	615	GM TublarBel	700	GM VoiceLead1	785	Pulse Wave7
446	Vox Lead1	531	AtmspherePd2	616	GM Dulcimer	701	GM VoiceLead2	786	Pulse Wave8
447	Vox Lead2	532	Steel Pad1	617	GM Organ 1	702	GM FifthLead1	787	Pulse Wave9
448	Charang1	533	Steel Pad2	618	GM Organ 21	703	GM FifthLead2	788	Pulse Wave10
449	Charang2	534	Steel Pad3	619	GM Organ 22	704	GM FifthLead3	789	White Noise
450	Pluck Lead1	535	Brightness1	620	GM Organ 31	705	GM FifthLead4	790	Pink Noise

CASIO®

カシオ計算機株式会社

〒151-8543 東京都渋谷区本町1-6-2

CASIO COMPUTER CO., LTD.

6-2, Hon-machi 1-chome
Shibuya-ku, Tokyo 151-8543, Japan

© MA1506-A Printed in China
Imprimé en Chine



PX560APPEND-WL-1A

© 2015 CASIO COMPUTER CO., LTD.